
Hi8 CAMCORDER

EVW-300

SERVICE MANUAL

Vol. 1 (1st Edition)



FIT81Hyper HAD,

SAFETY RELATED COMPONENT WARNING

Components identified by shading and \triangle marked on the schematic diagrams and parts list are critical to safe operation. Replace these components with SONY parts whose part numbers appear as shown in this manual or in supplements published by SONY.

このマニュアルに記載されている事柄の著作権は当社にあり、説明内容は機器購入者の使用を目的としています。 従って、当社の許可なしに無断で複写したり、説明内容(操作、保守等)と異なる目的で本マニュアルを使用することを禁止します。

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind.

Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

TABLE OF CONTENTS


1. SERVICE INFORMATION	3.	REPLACEMENT OF MAJOR PART
1-1. Cabinet Removal and Installation1-1		Preparation for Replacement of part3-1
1-2. Servicing of Mechanical Deck Block1-3	3-1.	Replacement of HC Roller Assembly3-2
1-2-1. Mechanical Deck Removal1-3	3-2.	Replacement of Guide Guard Assembly3-3
1-2-2. Mechanical Deck Extension1-4	3-3.	Replacement of DC Motor
1-2-3. SS-50/50P Board Extension1-4		(Capstan Motor)3-4
1-2-4. Removal and Installation of Cassette	3-4.	Replacement of S and T Brakes3-5
Compartment Assembly1-5	3-5.	Replacement of LB Brake and Shaft
1-3. Servicing of Printed Circuit Boards1-5		Holding Pin3-6
1-3-1. Removal of AU-162/162P Board1-5	3-6.	Replacement of LB Release Arm3-7
1-3-2. Removal of VO-43/43P Board1-6	3-7.	Replacement of RK Stopper and Stopper
1-3-3. Removal and Insertion of Board		Arm3-7
(AT-70, ES-4/4P, IE-33/33P, PR-159/159P	3-8.	Replacement of Pinch Arm Assembly and
Boards)1-6		TG-7 Arm Assembly
1-4. Modification When Installing DXF-50/40A	3-9.	Replacement of TG-2 Assembly3-9
Series1-7	3-10	
1-5. Location of Main Parts1-8	3-11	
1-5-1. Location of Main Mechanical	3-12	
Parts/Components1-8		Assembly and Tension Regulator Arm
1-5-2. Location of Printed Circuit Board1-10		Assembly
1-6. Printed Circuit Board1-13	3-13.	
1-7. Connectors	3-14	
1-8. Connector Input/Output Signal1-14		Condensation Sensor
1-9. Spare Parts	3.15	Replacement of Rotary Upper Drum and
1-10. How to Operate the Unit Without Cassette Tape	.0.10	Lower Drum3-16
(Muting of the Tape Beginning/End	3-16.	
Sensors)1-16	0-10.	Assembly and Pinch Sub Arm Assembly3-17
1-11. Cassette Tape Removal Procedure When	3-17.	
Normal Ejection is not Possible1-17	3-17.	Assembly, Loading Lever Assembly, Timing
1-11-1. Using the SELF DIAG mode1-17		Belt (S) and Connecting Gear Assembly3-18
1-11-2. Cassette Tape Removal in Case of	2.19	Replacement of Idler Pulley, TS Brake
Power Supply Trouble1-18	9-10.	Assembly, LB Gear Assembly and RK Gear
1-12. Fixtures		Assembly
1-13. Diagnostic mode1-21	2:10	
1-13. Blagnostic mode	3-19.	
	2 20	and LB Leaf Spring3-21
	3-20.	Replacement of Coaster (Right) Assembly and
1-16. Rec Pause Position Adjustment	0.01	Drive Gear (Right) Assembly3-22
1-17. Note on SS-50/50P Replacement1-37	3-21.	Replacement of Coaster (Left) Assembly and
1-18. Board Switch Settings	2.00	Drive Gear (Left) Assembly3-23
1-19. System Configuration	3-22.	
1-20. Level Check Sheet1-50		Release Arm, Wheel Gear and Worm
2. PERIODIC CHECK AND MAINTENANCE		Assembly3-25
0.1 36 1	4.	TORQUE AND BACK TENSION
2-1. Maintenance After Repairs2-1		ADJUSTMENT
2-1-1. Cleaning of Rotary Upper Drum2-1		
2-1-2. Cleaning of Tape Path System2-1	4-1.	FWD Back Tension Adjustment4-1
2-1-3. Cleaning of Drive System2-1	4-2.	Check of Reel Torque4-1
2-2. Periodic Check2-1	5.	TAPE PATH ADJUSTMENT
2-3. Hours Meter2-2		
2-4. Smear Grease2-3		Alignment Information5-1
2-5. Apply Oil2-4	5-1.	Preparation for Adjustment5-3
2-6. How to Use Cleaning Tape2-5	5-2.	Tracking Adjustment5-4
2-7. Others2-5	5-3.	Tracking Fine Adjustment5-4

5-4. No. 2 Guide Adjustment5-5	7. VTR ELECTRICAL ALIGNMENT
5-4-1. No. 2 Guide (TG-2) Height Preset5-5	7-1. Preparation7-1
5-4-2. No. 2 Guide (TG-2) Adjustment5-6	7-1-1. Equipment Required
5-5. No. 7 Guide (TG-7) Adjustment5-7	7-1-2. Adjustment Fixture
5-6. Check of CUE and REV Waveforms5-8	7-1-3. Connection
5-7. Check after Adjustment5-8	7-1-4. Initial Setting and Adjustment7-2
5-7-1. Tracking Check5-8	7-1-4. Initial Setting and Adjustment
5-7-2. Recovery Check of Waveform5-9	
5-7-3. Tape Running Check5-10	7-2. Servo System Adjustment
5-8. Switching Position Adjustment5-10	7-2-1. PWM Oscillation Frequency Adjustment7-4
C CAMEDA ALICAUMENT	7-3. Audio System Adjustment
6. CAMERA ALIGNLMENT	7-3-2. Audio AFM EE Level Adjustment7-4
6-1. Preparetion6-1	
6-1-1. Equipment Required6-1	7-3-3. PCM Master Clock Adjustment
6-1-2. Connection6-2	7-3-4. PCM Playback VCO Free-Frequency
6-1-3. Switch Setting Before Adjustment6-3	Adjustment7-5
6-1-4. Note on Adjustment6-3	7-3-5. Audio PCM D/A Converter Level
6-1-5. Adjustment Item6-3	Adjustment
6-2. CCD Drive System Adjustment6-4	7-3-6. Audio PCM NR Decode Level Adjustment 7-5
6-2-1. G/R/B V Substrate Voltage Adjustment 6-4	7-3-7. Audio PCM A/D Converter offset
6-2-2. G/R/B RG Voltage Adjustment6-4	Adjustment
6-3. SYNC Signal System Adjustment6-5	7-3-8. PCM 1 EE Level Adjustment
6-3-1. Sub-carrier Frequency Adjustment6-5	7-3-9. PCM 2 EE Adjustment
6-4. Encoder System Adjustment6-5	7-3-10. PCM 1 REC Level Adjustment7-7
6-4-1. Color-Bar 75%/100% Adjustment6-5	7-3-11. PCM 2 REC Level Adjustment7-7
6-4-2. Carrier Balance Adjustment6-6	7-3-12. Line AU-1 Monitor out Level
6-4-3. Color-Bar Size Adjustment6-6	Adjustment7-7
6-4-4. Int CB Y Adjustment6-7	7-3-13. Line AU-2 Monitor out Level
6-4-5. Color Vector Adjustment6-7	Adjustment7-7
6-4-6. Matrix Adjustment6-8	7-3-14. PCM 1 meter Adjustment
6-5. Video Process System Adjustment6-9	7-3-15. PCM 2 meter Adjustment
6-5-1. 1H Out Balance Adjustment6-9	7-3-16. AFM meter Adjustment7-8
6-5-2. 2H Out Balance Adjustment6-10	7-3-17. Battery meter Adjustment7-9
6-5-3. 1H GAIN Adjustment6-11	7-3-18. Audio AFM Carrier Frequency
6-5-4. 2H GAIN Adjustment6-12	Adjustment7-9
6-5-5. G-ch/B-ch/R-ch Input GAIN Adjustment6-13	7-3-19. AFM Deviation Adjustment
6-5-6. G-ch GAIN/GAMMA/PED Adjustment6-14	7-3-20. PCM REC Current Adjustment7-10
6-5-7. R-ch/B-ch GAIN/PED Adjustment6-15	7-4. Video System Adjustment
6-5-8. G-ch Black Set and Pedestal Adjustment 4.6-16	7-4-1. PB RF Frequency Adjustment7-11
6-5-9. R-ch/B-ch Black Set and Pedesta	7-4-2. REC Y Adjustment
Adjustment6-16	7-4-3. Y/C Sep Frequency Adjustment
6-5-10. Knee Adjustment6-17	7-4-4. IR Adjustment7-13
6-5-11. Pre Knee Adjustment6-18	7-4-5. Emphasis Level Adjustment7-13
6-5-12. PR White Clip Adjustment6-18	7-4-6. Chroma Emphasis Adjustment7-14
6-5-13. Aliasing Adjustment6-19	7-4-7. Hi8 mode PB Y Level Adjustment
6-5-14. Aperture Crispening Adjustment6-20	7-4-8. STD mode PB Y Level Adjustment7-15
6-5-15. Y _H Level Adjustment	7-4-9. PB Y Level Adjustment
6-5-16. DTL Crispening Adjustment	7-4-10. EE Line out Level Adjustment7-15
6-5-17. DTL Aliasing Adjustment	7-4-11. PB Line out Level Adjustment
6-5-18. H/V Ratio Adjustment	7-4-12. Low Band mode Y FM Carrier
6-5-19. Detail Level Adjustment	Adjustment7-16
6-5-20. ES White Clip Adjustment	7-4-13. Low Band mode Y FM Deviation
6-5-21. Zebra Level Adjustment	Adjustment7-17
6.5.22 Auto Iris Adjustment	7-4-14. Hi8 mode Y FM Carrier Adjustment7-17

7-4-15.	Hi8 mode Y FM Deviation Adjustment7-17
7-4-16.	REC Video REC Current Level
	Adjustment7-18
7-4-17.	REC Chroma REC Current Adjustment7-19
7-4-18.	REC AFM REC Current Adjustment7-20
7-4-19.	Chroma Cancel Balance Adjustment7-21
	C Correlation Phase Adjustment 17-21
	C Correlation Phase Adjustment 27-21
7-4-22.	C Correlation Phase Adjustment 37-22
7-4-23.	EE Video out Chroma Level Adjustment7-22
7-1-21	PR Chroma Level Adjustment7-22




SECTION 1 SERVICE INFORMATION



1-2. SERVICING OF MECHANICAL DECK BLOCK


1-2-1. Mechanical Deck Removal

- 1. Remove the side panel (left) according to section 1-1.
- 2. Remove the four fixing screws shown in the figure, then open the mechanical deck in the direction of the arrow.



- Disconnect the connectors CN101, CN106 and CN107 of the flexible card wires from the SS-50/50P Board.
- Raise the mechanical deck, then remove support screw
 from the receptacle (lower).
- Pull out support screw (A) of the mechanical deck and also the stopper screw, in the downward direction from the receptacle (upper).

Note: When removing the mechanical deck, hold the sheet metal part around the mechanical deck to prevent the mechanical deck from being subjected to a load.



1-2-2. Mechanical Deck Extension


Fixtures: SS Extension Flexible Card Wires JH-099 (26P) (J-6360-990-A) two JH-100 (14P) (J-6361-000-A) one

- 1. Remove the mechanical deck according to section 1-2-1.
- 2. Insert the extension flexible card wires as shown below, ensuring that they go as far as the base of the mating connectors on the SS-50/50P board, then push down each connector locking piece as shown in Fig. 1 until the connector locks.

 SS-50/50P board, 	 SS extension
	flexible card wire
CN106 -	JH-099
CN101	JH-100
CN107	— JH-099

Note: When inserting the flexible card wires, ensure that the insulated part (white part) of each flexible wire is on the side nearer you.

3. Connect each extension flexible card wire to flexible harness FL-125 on the MB-381/381P board, in sequence from the top.




1-2-3. SS-50/50P Board Extension

Fixtures: SS Extension Flexible Card Wires JH-099 (26P) (J-6360-990-A) two JH-100 (14P) (J-6361-000-A) one JH-101 (13P) (J-6361-010-A) one JH-102 (11P) (J-6360-020-A) one


Extend the SS-50/50P board as follows when it is necessary to check the soldering side of the SS-50/50P board or the rear of the mechanical deck.

- 1. Extend the mechanical deck according to section 1-2-2.
- 2. Disconnect the two connectors CN1 and CN2 of the flexible card wire from the SS-50/50P Board.
- 3. Remove the two screws, then open the SS-50/50P board.
- Insert the extension flexible card wires to the base of the mating connectors on the SS-50/50P board, as shown below.



Note: When inserting the flexible card wires, ensure that the insulated part (white part) of each flexible wire is on the component side.


- 5. Connect the SS extension card wire JH-101 to the connector of the flexible card wire FP-89.
- Connect the SS extension card wire JH-102 to the connector of the flexible card wire FP-90.



1-2-4. Removal and Installation of Cassette Compartment Assembly


Removal

- 1. Remove the side panel (left) according to section 1-1.
- Remove the two fixing screws, then remove the cassette compartment assembly in the direction of the arrow.



Installation

- 1. Extend the SS-50/50P board according to section 1-2-3.
- 2. Turn on the power and set to the threading mode according to Section 1-10.
- 3. After the threading mode is completed, turn off the nower.
- 4. Put two claws of the cassette compartment to the holes, ensuring that the A part is on the loading motor side of the B part of the EJECT lever, then fix the cassette compartment assembly with the two fixing screws.




Turn on the power and confirm that the cassette compartment rises by pressing the EJECT button.

1-3. SERVICING OF PRINTED CIRCUIT BOARDS

1-3-1. Removal of AU-162/162P Board


- 1. Loosen the four screws, and open the side panel (right).
- 2. Disconnect the two connectors CN1 and CN2 of the flexible card wires from the AU-162/162P board.
- 3. Remove the two screws and two hinges and remove the AU-162/162P Board.



1-3-2. Removal of VO-43/43P Board

- Remove the AU-162/162P board according to section 1-4-1.
- Disconnect the two connectors CN1 and CN2 of the flexible card wires from the VO-43/43P Board.
- Remove two fixing screws and open the VO-43/43P


 Board
- Raise the VO-43/43P board, then remove support screw
 from the receptacle (lower).
- 5. Pull out support screw (A) and the stopper screw of the VO-43/43P board from the receptacle (upper).



1-3-3. Removal and Insertion of Board (AT-70, ES-4/4P, IE-33/33P, PR-159/159P Boards)

Removal

- 1. Loosen the four screws, and open the side panel (right).
- Grasp the board with the fingers, avoiding the components mounted on it, then pull it out while moving it gently up and down.



Installation

1. Align the edges of the board with the upper and lower rail grooves, then push in the board as far as it will go.


1-4. MODIFICATION WHEN INSTALLING DXF-50/40A SERIES

It is necessary to carry out the following modification when installing the DXF-50/40A series viewfinder.


Parts to be obtained

Shoe (3-664-218-11) one Leaf spring (3-664-228-00) one Stopper screw (3-664-213-00) one Screw $+K3\times6$ (7-682-247-04) four

1. Remove the two screws, then remove the handle lid.



2. Install the shoe using the four screws ($+K3\times6$), then install the leaf spring with the stopper screw.




1-7

EVW-300 (UC)

1-5. LOCATION OF MAIN PARTS


1-5-1. Location of Main Mechanical Parts/Components

TOP VIEW



- ① Tape Top/End LED ② Pinch Roller Assembly
- ③ Capstan Shaft
- ④ Drum Assembly
- ⑤ S Side Reel Table⑥ T Side Reel Table⑦ RECOG. switch

BOTTOM VIEW




- 8 Tape End Sensor9 Loading Motor Assembly
- 1 Drum Assembly
- ① Capstan Motor

- ② Timing Belt S③ Tape End Sensor④ Timing Belt L⑤ RK Gear Assembly


1-5-2. Location of Printed Circuit Board

Main part (1)




- ① SW-484 BOARD
- ② SW-506 BOARD
- ③ SW-485 BOARD
- ④ FP-40/40P BOARD
- ⑤ CP-188 BOARD
- 6 CP-221 BOARD
- ⑦ CP-189 BOARD
- ® CP-184 BOARD
- 9 KY-191 BOARD
- **10** SW-507 BOARD

Main part (2)



- PR-159/159P BOARD
 IE-33/33P BOARD
 ES-4/4P BOARD
 AT-70 BOARD
 MB-381/381P BOARD
- (b) AU-162/162P BOARD (f) CR-43/43P BOARD (f) VO-43/43P BOARD (f) MB-384/384P BOARD

Mechanical Deck



- SS-50/50P BOARD
 FP-89 FLEXIBLE CARD WIRE
 FP-90 FLEXIBLE CARD WIRE
 SBX-1508 BOARD

1-6. PRINTED CIRCUIT BOARD

CAMERA

CHIVIDICI		
SYSTEM	BOARD	CIRCUIT FUNCTION
	IE-33	VIDEO AMP IMAGE ENHANCER COLOR BAR GENERATOR
VIDEO	PR-159	VIDEO PROCESS
	ES-4	CHROMA ENCODER SYNC GENERATOR
SYSCON	AT-70	CAMERA SYSTEM CONTROL
	MB-384	MOTHER BOARD CCD TIMING PULSE GENERATOR
Others	SW-484 SW-485 SW-506 SW-507	MODE SW

VTR

SYSTEM	BOARD	CIRCUIT FUNCTION
VIDEO	VO-43	REC Y/C/AFM/ATF MIX Y PROCESS
	CR-43	CHROMA PROCESS
	AU-162	PCM AUDIO PROCESS
AUDIO	FP-40	AUDIO INPUT/OUTPUT AMP
	CP-188	EARPHONE JACK
TIME CODE	AU-162	TIME CODE PROCESS
	SS-50	VTR SYSTEM CONTROL SERVO SYSTEM, MECHANISM CONTROL ATF SERVO
SYSCON	MB-381	TAPE TOP/END SENSOR
SERVO	KY-191	FUNCTION KEY BOARD
	FP-40	MODE SW BACK TALLY
7	MB-381	MOTHER BOARD
Others	CP-184 CP-188 CP-189	CONNECTOR PANEL
	CP-221	REMOTE LED
	SBX-1508	RP AMP

1-7. CONNECTORS

When external cables are connected to the various connectors of the connector box during maintenance, the hardware listed below or equivalents must be used.

PANEL INDICATION	CONNECTOR
VIDEO OUT	1-560-069-11
	PLUG, BNC
	or B-B cable assembly
(BNC)	(Cable length 1.5m, optional)
VF	9-994-797-01
(8P, FEMALE)	CABLE, VF
OPTION	1-560-078-00
	PLUG, 6P MALE
	HIROSE HR10-7PA-6P (3)
	equality
	1-560-078-21
	PLUG, 6P MALE
	HIROSE HR10-7PA-6P equality
	1-566-365-11
	PLUG. 6P MALE
	HIROSE HR10A-7P-6P (01)
	equality
	1-566-365-21
	PLUG. 6P MALE
	HIROSE HR10A-7P-6P (02)
(6P, FEMALE)	equality
DC	1-508-362-00
	PLUG, 4P FEMALE
(4P, MALE)	CANON XLR-4-11C equality
MIC	1-508-084-00
	PLUG, 3P MALE
(3P, FEMALE)	CANON XLR-3-12C equality

1-8. CONNECTOR INPUT/OUTPUT SIGNAL

[INPUT]

GENLOCK IN; BNC Type 1Vp-p, 75Ω

[OUTPUT]

CAMERA VIDEO OUT; BNC Type Composite signal

 $1.0 \text{Vp-p} \pm 1.0 \text{dB}, 75\Omega$

negative sync, unbalanced

AUDIO OUT L/R; Pin jack type $-10 dBu, 47 k\Omega$ unbalanced

VIDEO OUT; BNC Type

VIDEO OUT; Pin jack type Composite signal


 $1.0 \text{Vp-p} \pm 1.0 \text{dB}, 75\Omega$

negative sync, unbalanced

RFU DC OUT; Special mini jack

5V DC

LENS (7P)



(WIRING SIDE)

Pin No.	Signal	Specification
1	VF VIDEO CONT IN	ON: 0±5Vdc
2	VTR START/STOP IN	TRIG: 0±0.5V
3	POWER +12V DC GND	GND for +12Vdc
4	COMPULSORY AUTO IRIS CONT OUT	5±0.5Vdc
5	IRIS CONT OUT	F16: 3.4Vdc F2.8: 6.2Vdc
6	POWER +12V DC OUT	10.5V to 17Vdc, 3A
7	(SPARE)	

VF (8P, FEMALE)



(WIRING SIDE)

OPTION (6P, FEMALE)



(WIRING SIDE)

Pin No.	Signal	Specification
1	POWER +12V DC GND	GND for +12Vdc
2	REC TALLY IND OUT	Zo≦1.1kΩ
3	E. SHUTTER IND OUT	Zo≦1.1kΩ
4	VF VIDEO (G) OUT	GND for VF VIDEO
5	BATT IND OUT	Zo≦1.1kΩ
6	VF VIDEO (X) OUT	V=1Vp-p
7	POWER +12V DC OUT	10.5V to 17Vdc, 3A
8	GAIN UP IND OUT	Zo≦1.1kΩ

Pin No.	Signal	Specification
1	VF VIDEO CONT IN	ON: 0±0.5Vdc
2	VTR START/STOP IN	TRIG: 0±0.5V
3	POWER +12V DC GND	GND for +12Vdc
4	COMPULSORY AUTO IRIS CONT OUT	5±0.5Vdc
5	IRIS CONT OUT	F16: 3.4Vdc F2.8: 6.2Vdc
6	POWER +12V DC OUT	10.5V to 17Vdc, 3A



(EXT VIEW)

No.	Signal	Specification
1	EXT DC IN (G)	GND
2		
3		
4	EXT DC IN (X)	10.5 to 17.0Vdc

MIC (3P, FEMALE)



(EXT VIEW)

No.	Signal	Specification
1	MIC IN (G)	GND
2	MIC IN (X)	MIC: −60dBu Zi≥3kΩ BALANCED
3	MIC IN (Y)	LINE: +4dBu Zi≥10kΩ BALANCED

S VIDEO (4P, FEMALE)



(EXT VIEW)

No.	Signal	Specification
1	LUMINANCE OUT (G)	GND for LUMINANCE
2	CHROMINANCE OUT (G)	GND for CHROMINANCE
3	LUMINANCE OUT (X)	$1.0 \mathrm{Vp}\text{-p}\pm 1.0 \mathrm{dB}, 75\Omega$ unbalanced, negative sync
4	CHROMINANCE OUT (X)	$0.286 \mathrm{Vp-p} \pm 1.0 \mathrm{dB}, 75 \Omega$ unbalanced

1-9. SPARE PARTS


- The <u>M</u>-marked components are critical to safety. Replace only with same components as specified.
- (2) Replacement parts supplied from the Sony Parts Center will sometimes have a different shape from the original parts. This is due to accommodating the improved parts and/or engineering changes or standardization of genuine parts. This manual's exploded views and electrical spare parts list indicate the part numbers of the standardized gunuine parts at the present. Regarding engineering part changes in our engineering department, refer to Sony service bulletins and service manual supplements.
- (3) The parts marked with s in the SP column of the exploded views and electrical spare parts list are normally stocked for replacement purposes. The parts marked with o in the SP column are not normally required for routine service work. Orders for parts marked with o will be processed, but allow for additional delivery time.

1-10. HOW TO OPERATE THE UNIT WITHOUT CASSETTE TAPE (MUTING OF THE TAPE BEGINNING/ END SENSORS)


- When replacing mechanical parts, sometimes there is a
 case need to select modes without cassette tape inserting.
 Mute the tape top/end sensors in the following ways and
 then operate the unit. If using the mode selector, it is to
 necessary to mute the tape top/end sensors.
- (1) Using the SELF DIAG mode
 - Turn on the [SELF DIAG] switch on the side of the unit.
 - 2. Set the [R-RUN/SET/F-RUN] switch to SET side.
 - 3. Select menu "103" by pressing [ADVANCE] or [SHIFT] button.




4. Set the [R-RUN/SET/F-RUN] switch to R-RUN side and select data "20" by pressing [ADVANCE] or [SHIFT] button.



- 5. The tape top/end sensors will be muted by pressing the [COUNTER RESET] button.
- 6. Turn off the [SELF DIAG] switch. Turn off the power momentarily.



(2) Put an opaque cap on the LED as shown in the figure.



1-11. CASSETTE TAPE REMOVAL PROCEDURE WHEN NORMAL EJECTION IS NOT POSSIBLE

When the cassette tape cannot be ejected from the unit because the tape is wound around the drum, take the following action.

1-11-1. Using the SELF DIAG mode

- 1. Remove the cassette lid and side panel (left) according to Section 1-1.
- 2. Turn on the [SELF DIAG] switch on the side of the unit.
- 3. Set the [R-RUN/SET/F-RUN] switch to SET side.
- 4. Select menu "103" by pressing [ADVANCE] or [SHIFT] button.




- 5. Set the [R-RUN/SET/F-RUN] switch to R-RUN side.
- 6. Select data "10" by pressing [ADVANCE] or [SHIFT] button.



- 7. Press the [COUNTER RESET] button.
- 8. Operate the [F FWD] or [REW] button on the top panel to unthread. (Press the [STOP] button to stop unthreading.) Move that No. 5 and No. 6 guides of the coaster (right) assembly in order to be placed as shown in the Fig. 1. Check that the No. 5 and No. 6 guides are not under the HC roller assembly.
- 9. Remove the tape from the No.1 through No.7 guides and pinch roller assembly.
 - Note 1: When removing the tape from the guides, be careful not to damege it.
 - Note 2: The mechanical chassis's sliding portion of the coaster (right) and (left) assemblies are smeared grease. Do not be adhered grease to the tape.
- 10. Turn the rotor of the capstan motor in the direction of arrow A or B by hand and wind up the tape into the cassette. (Fig. 2)

The direction of arrow A: wind up the tape to S side The direction of arrow B: wind up the tape to T side

- 11. Push the arrow of lock lever by hand as shown in Fig. 3 and eject the cassette tape.
- Turn off the [SELF DIAG] switch. Turn off the power momentarily.




1-11-2. Cassette Tape Removal in Case of Power Supply Trouble

• Using the mode selector


Fixture: Mode Selector (J-6080-825-A)

- Remove the cassette lid and side panel (left) according to section 1-1.
- 2. Touch two clips of the mode selector to the terminals of the loading motor. (Fig. 4) Operate the [LOAD] or [UNLOAD] button of the mode selector to unthread. Move that No. 5 and No. 6 guides of the coaster (right) assembly in order to be placed as shown in the Fig. 1. Check that the No. 5 and No. 6 guides are not under the HC roller assembly.



Eject the cassette tape according to section 1-11-1, procedures 9 to 11.

- Not using the mode selector
- Remove the cassette lid and side panel (left) according to section 1-1.
- 2. Remove the side panel (right) according to section 1-1.
- 3. Remove the SS-50/50P board according to section 1-4.
- 4. Turn the worm gear of the loading motor in the direction of the arrow with a thin rod etc.. (Fig. 5) Move that the No. 5 and No. 6 guides of the coaster (right) assembly in order to be placed as shown in Fig. 1. Check that the No. 5 and No. 6 guides are not under the HC roller assembly.




5. Eject the cassette tape according to section 1-11-1, procedures 9 to 11.

1-12. FIXTURES

Ref. No. Parts No.		Description	Application
J-1	7-700-766-01	Hexagonal Screwdriver (0.89mm)	Tape Path Adjustment
J-2	7-741-900-53	Wiping Cloth	Cleaning
J-3	8-967-992-12	Alignment Tape, WR2-3NS	Switching Position Adjustment
J-4	8-967-995-02	Alignment Tape, WR5-1NP	Tape Path Adjustment
J-5	8-967-995-13	Alignment Tape, WR5-7NE	Video Frequency Response Adjustment
J-6	8-967-995-42	Alignment Tape, WR5-5NSP	Video Adjustment
J-7	8-967-995-43	Alignment Tape, WR5-8NSE	Audio and Video Adjustment (SP)
J-8	J-6080-824-A	FWD, REV Winding Torque Cassette	S and T Reel Tables Winding Torque Check
J-9	J-6080-825-A	Mode Selector	Check, Adjustment and Replacement of Mechanical Block
J-10	J-6080-840-A	Small Adjustment Mirror	Tape Path Adjustment
J-11	J-6082-021-A	Mode Selector III Conversion Connector	Check, Adjustment and Replacement of Mechanical Block
J-12	J-6082-023-A	Mode Selector III Panel	Check, Adjustment and Replacement of Mechanical Block
J-13	Y-2031-001-1	Cleaning Fluid	Cleaning
J-14	-	Rotary Drum Tool (supplied accessory of Repair Rotary Upper Drum)	Replacement of Rotary Upper Drum
J-15	Commercially Sold	Head Degausser	Head Degauss
J-16	J-6365-410-A	Tracking Adjustment Tool (JH-541)	Tracking Adjustment
J-17	J-6391-180-A	Extension Board (EX-337)	Check and Adjustment of Boards
J-18	J-6360-990-A	SS Extension Flexible Card Wire (JH-099) (26P)	Check of SS Board and Mechanical Deck * 1
J-19	J-6361-000-A	SS Extension Flexible Card Wire (JH-100) (14P)	Check of SS Board and Mechanical Deck
J-20	J-6361-010-A	SS Extension Flexible Card Wire (JH-101) (13P)	Check of SS Board and Mechanical Deck
J-21	J-6361-020-A	SS Extension Flexible Card Wire (JH-102) (11P)	Check of SS Board and Mechani cal Deck

^{* 1} Two SS extension card wires are required to extend the SS board and mechanical deck.




1-13. DIAGNOSTIC MODE

The LCD display on the side of the EVW-300/300P can be set to provide an hourmeter indication, the battery end/near end voltage setting, and also a self diagnostic display.

Operation method

1. Set the [SELF DIAG] switch on the side of the unit to ON.



(Menu 102 will appear on the LCD display. VTR OUT will go into the external input mode.)

- 2. To move the menu, set to the [R-RUN/SET/F-RUN] switch on the side of the unit to SET.
- 3. Press the [ADVANCE] or [SHIFT] button on the side of the unit, and select the desired menu.
- 4. To move data, set the [R-RUN/SET/F-RUN] switch to R-RUN, then press the [ADVANCE] or [SHIFT] button to select the data. By pressing the [COUNTER RESET] button, the data will be stored.
- 5. Finally, set the [SELF DIAG] switch to OFF, and turn off the power momentarily.

Mode table

Menu	Menu description	LCD display	Description
102	External select E • E mode menu	102 0000	Factory adjustment mode When the unit is put into this mode, the signal from VTR VIDEO OUT is not output, however this is not
			a fault.
103	Motor manual control menu	[ID3 ID]	Loading motor control Put the unit into this mode to remove a cassette tape
			when the tape is wound around the drum. For details, refer to section 1-11.
		11 EOI	Drum control Put the unit into this mode to check the rotation system of the drum. Rotate the drum by pressing the [F FWD] or [REW] button at the top of the unit. Stop rotation by pressing the [STOP] button.
		103 IS	Capstan control Put the unit into this mode when checking the rotation system of the capstan motor. Rotate the capstan motor by pressing the [F FWD] or [REW] button at the top of the unit. Stop rotation by pressing the [STOP] button.
		103 20	Tape top/end sensor muting Put the unit into this mode to operate the VTR without cassette tape. For details, refer to section 1-10.
104	VTR adjustment mode menu	104 4	Head framing OFF
		104 0	Head framing ON
		IOH I	This mode is not used. Head framing OFF

Menu	Menu description	LCD display	Description
1971 - 1971		104 2	VTR adjustment 2. Enter this mode to perform Y/C SEP and IR adjustments. For details, refer to section 8. Head framing OFF
		104 3	This mode is not used. Head framing OFF
105	ATF 1/3 shift adjustment menu	105 00	NO ACTIVE
		105 11	Enter this mode when performing tracking adjustment. For details, refer to section 5.
201	HOURMETER [ON period] display menu	201 xxxx	Displays the total period during which the unit is turned ON. The actual ON period is 10 times the displayed value.
			e.g. A displayed value of 0001 means 10 hours. Refer to the address map (5) to see the displayed value for an ON period of less than 10 hours.
202	HOURMETER (drum) display menu	202 xxxx	Displays the total period during which the drum rotates. The actual rotation period is 10 times the displayed value.
			e.g. A displayed value of 0001 means 10 hours. Refer to the address map (5) to see the displayed value for a drum rotation period of less than 10 hours.
203	Emergency code menu Tape top/end menu	203 ××	Displays the contents of an existing abnormality. For details, refer to the address map (7).
204	REC PAUSE position adjustment menu	204 ××	Used to adjust the REC PAUSE position. For details, see section 1-15.
205	Loading operation count display menu	205 xxxx	Used to display the number of loading operations of the unit. [R-RUN/SET/F-RUN] switch → [SET] position The number of loading operations is equal to 256 times the displayed value (hexadecimal value). e.g. value of 0001 → 256 operations
		xxxxx	[R-RUN/SET/F-RUN] switch → [R-RUN] position The number of loading operations is displayed on all digits. (hexadecimal value)
501	Initialize menu Note: Before entering this mode, connect TP502 and GND (E1) on the FP-40/40P board with a	50 1 02	NTSC parameter set RESET during overhaul
	shorting clip.	501 11	Enter this mode to set the default values of the BATTERY END/NEAR END voltage, LITHIUM BATTERY END voltage and switching position. Be sure to set the default value after replacing the SS-50/50P board or after replacing IC108 on the SS-50/50P board.

Menu	Menu description	LCD display	Description
503	Battery end setting menu	503 ××	Enter this mode to set the battery end voltage. For details, refer to section 1-14.
504	Battery near end setting menu	504 xx	Enter this mode to set the battery near end voltage. For details, refer to section 1-14.
505	Memory/EEPROM scan display menu	CCSC ×× ×× Table 1	Final mechanical mode This mode is used to display the final mechanical operation of the unit. (See Table 1.)
	Set the [R-RUN/SET/F-RUN] switch to the R-RUN position		Actual mechanical mode Displays the actual mechanical operation of the unit. (See Table 1.)
	using this screen, then select arbitrary data using the [ADVANCE] or [SHIFT] but- ton. Refer to the address maps (1) to	Table 2	Emergency mode (first) Use this mode when analyzing the cause of a defect in the unit after switching it OFF. The cause of the first defect that occurred will be displayed. (See Table 2.)
	(6) for details of modes other than the modes shown at right.	Table 2	Emergency mode (final) Use this mode when analyzing the cause of a defection the unit after switching it OFF. The cause of the last defect that occurred will be displayed. (See Table 2.)
		Table 1	Emergency mechanical mode (first) Use this mode when analyzing the cause of a defection the unit after switching it OFF. The mechanical mode corresponding to the defect that occurred first will be displayed. (See Table 1
		GGGB xx xx Table 1	Emergency mechanical mode (final) Use this mode when analyzing the cause of a defer in the unit after switching it OFF. The mechanical mode corresponding to the defer that occurred last will be displayed. (See Table 1)
506	EEPROM change display	506 ××××	The data in the EEPROM can be changed. For details, see the address map (1).
507	RAM memory change menu	0040 xxxx	The video data can be changed manually. For details, refer to address map (6).
	Set the [R-RUN/SET/F-RUN] switch to the R-RUN position using this screen, then select the following data using the [ADVANCE] or [SHIFT] button and then press the [COUNTER RESET] button.		
101	SW POSITION adjustment	ID I xxxx	Used when adjusting the switching position.
	menu	ILI I XXXX	For details, refer to section 5-8.

Table 1

	Dis	olay		Dis	play
Meaning of display	MECH mode	MECH mode	Meaning of display	MECH mode	MECH mode
	(NORMAL)	(EMERGENCY)		(NORMAL)	(EMERGENCY)
EJECT	01	10	FF	03	30
EJECT DEW	11	11	REW	83	38
TAPE UNLOADING	31	13	REC	04	40
NORMAL STOP	02	20	REC PAUSE	14	41
TAPE LOADING	12	21	AUDIO DUB	84	48
BATTERY DOWN STOP	32	23	AUDIO DUB PAUSE	94	49
STOP DEW	42	24	FRAME REC	A4	4A
STOP EMERGENCY	52	25	REC PAUSE TOP	B4	4B
TAPE END STOP	62	26	EDIT SEARCH CUE	25	52
STOP TAPE TOP	72	27	EDIT SEARCH REVIEW	35	53
STOP ZERO	92	29	REC REVIEW FORWARD	85	58
STOP EMERGENCY #0	A2	2A	REC REVIEW REVERSE	95	59
STOP EMERGENCY #1	B2	2B	EDIT SEARCH FORWARD	A5	5A
STOP EMERGENCY #2	C2	2C	EDIT SEARCH REVERSE	B5	5B
UNLOAD STOP	E2	2E	EDIT SEARCH PAUSE	F5	5F
	,	.	PB	06	60
			×1	26	62
			REVERSE (-×1)	36	- 63

Table 2

Trouble	Dis	play	Can tape be ejected?
Normal operation	00	00	No
Loading motor trouble	00	01	
REEL FG trouble when unthreading	00	02	
REEL FG trouble except when unthreading	00	04	
Capstan motor trouble	00	08	
Drum FG trouble when rotating	01	00	Yes
Drum PG trouble when rotating	02	00	· [
FG trouble when the drum rises up	21	00	
PG trouble when the drum rises up	22	00	
Drum FG trouble when threading	41	00	
Drum PG trouble when threading	42	00	
Drum FG trouble when unthreading	81	00	
Drum PG trouble when unthreading	82	00	
Phase trouble when drum is rotating			₩

Use the address map to obtain more detailed data in the self diagnostic mode. Refer to menu "505" of section 1-13 "DIAGNOS-TIC MODE" for the method of displaying the address.

Address map (1) (Menu 505, 506)

This map is used mainly to enable the history of the unit to be checked.

Position of Set value

LCD display Set value

Example: By setting the address to "0212", the set values of addresses "0213", "0012" and "0013" can be seen simultaneously. On the display at left, the set value "58" of address 0213 can be displayed at (A).

Only even numbers can be displayed.

Menu 505	* 1 Menu 506	Position						Set			
Address	Address	of set value	Contents								
(LCD display)	(LCD display)	value									
0200	aaaa	B									
(020 1)	(000)	A	MODE NTSC: Set value 1b PAL: Set value 9b					1b			
0202	0002	B	When bit 0 is 0, the EN LI WARN status i When bit 1 is 1, the EN BC BACK TALLY		t			※ 2			
0204	0004	B	Switching position (lower digits); Value se	t with menu	101			Adj. value			
(0205)	(0005)	(A)	Switching position (upper digits); Value se	t with menu	101			Adj. value			
0208	0006	₿	Battery A/D conversion value (END); Value	Sattery A/D conversion value (END); Value set with menu 503							
(0207)	(0007)	(A)	Battery END set area	Battery END set area							
0208	0008	(B)	Battery A/D conversion value (NEAR ENI	Battery A/D conversion value (NEAR END); Value set with menu 505							
(0209)	(0009)	(A)	Battery NEAR END set area					Adj. value			
02 IO	00 10	®	SR data storage area	EDIT OFF	MP	Hi-8	LP	6F			
(0211)	(0011)	(A)	SR data storage area	EDIT OFF	MP	Hi-8	SP	65			
ם ופֿ	00 12	®	SR data storage area	EDIT OFF	MP	NOR	LP	5C			
(02 (3)	(81 00)	(A)	SR data storage area	EDIT OFF	MP	NOR	SP	58			
02 14	00 14	B	SR data storage area	SR data storage area EDIT OFF ME Hi-8 LP							
(02 15)	(00 15)	(A)	SR data storage area	EDIT OFF	ME	Hi-8	SP	65			

Address in perenthesis () is not displayed on the LCD display. To confirm its set value, display the even-number address and read the value as shown in the above illustration.

Menu 505	* 1 Menu 506	Position		Cat
Address (LCD display)	Address (LCD display)	of set value	Contents	Set value
02 16	00 16	®	SR data storage area EDIT OFF ME NOR LP	5C
(02 17)	(00 17)	A	SR data storage area EDIT OFF ME NOR SP	58
0220	0020	B	Code for abnormality that occurred first (lower digits) (first emergency mode)	₩ 3
(022.0)	(0021)	(A)	Code for abnormality that occurred first (upper digits) (first emergency mode)	₩ 3
0222	0022	B	Mechanical mode when an abnormality occurred first (first emergency mode)	₩ 3
0224	0024	₿	Code for an abnormality that occurred last (lower digits) (final emergency mode)	※ 3
(0225)	(0025)	A	Code for an abnormality that occurred last (upper digits) (final emergency mode)	* 3
0226	0028	B	Mechanical mode when an abnormality occurred last (final emergency mode)	* 3
0230	0030	®	POWER ON HOURS DATA	※ 4
0232	0032	®	POWER ON HOURS DATA XXXX DATA DATA X1000 hours (upper digits)	
0234	0034	®	DRUM HOURS DATA [1234 xxxx] DATA ® ×10 hours (lower digits)	※ 5
0236	0036	(B)	DRUM HOURS DATA [1235 xxxx] DATA ® ×1000 hours (upper digits)	
0240	0040	(B)	REC PAUSE SLOW TRANCON (00 to FF)	※ 6
0242	0042	B	LI BATTERY END SETTING (2.5V)	7F
0244	0044	(B)	LOADING DATA DATA×256 times	* 7


- * 1 This is the map for menu 506.

 Normally, it is not used. Use menu 505 to observe the contents of the data.
- * 2 Address 0202 display



Set Bit value	7	6	5	4	3	2	1	0	Set contents (operation)
00	0	0	0	0	0	.0	0	0	Lithium battery warning
00		()			- ()		Ditinum battery warming
01	0 0 0 0			0	0	0	1	No display or warning (BC BACK TALLY and lithium battery)	
01	0		1				No display of warning (be back table and number battery)		
02	0	0	0	0	0	0	1	0	BC BACK TALLY display + lithium battery warning
02	0 2 BC BACK			BC BACK TADDI display Indiddin battery warning					
03	0	0	0	0	0	0	1	1	BC BACK TALLY display
03		()				3		BC BACK TALLI display

The "BATT" part at the bottom of the LCD display flashes as a warning to indicate that the voltage of the lithium battery has dropped.



- * 3 The state of the unit in the event of an abnormality is indicated. See Tables 1 and 2 on the previous page for details.
- * 4 The total period during which the unit is turned on is indicated. For details, see the description in menu 201. Refer to the address map (5) to see the displayed value for an ON period of less than 10 hours.
- * 5 The total period of rotation of the drum is indicated. For details, see the description in menu 202. Refer to address map (5) to see the displayed value for drum rotation period of less than 10 hours.
- * 6 The set value differs depending on the unit, however it is "F0" in almost all cases. The factory setting can be seen by selecting menu 204. Refer to section 1-15 for details on adjustment.
- * 7 You can observe the number of loading operations.

 Multiply the number displayed as the set value by 256. For example, if the indicated set value is "02", the actual value will be 2×256=512 operations. Refer to the address map (5) if the number of loading operations is less than 256.

Address map (2) (Menu 505)

Enables the status of the unit to be checked.

LCD display

0050×× 🔲

e.g. If the indication on the LCD display is "006E"

Hexadecimal indication

Φ									
Bit	7	6	5	4	3	2	1	0	
1 or 0	1	0	0	1	0	0	1	-1	
Hexadecimal number	8	0	0	1	0	0	2	1	
	9								

				<u>, </u>										
Address (LCD display)	Bit7	Bit6 Bit5		Bit4	Bit3	Bit2	Bit1	Bit0	Remark					
0050	Same as CCSC ×××× of menu 505													
0088	1: MP 0: ME	1: PB 0: EE	(** 1) 0: AGC SLOW	1: Always "1"	1: JOG ON	1: VIDEO MUTE	1: LP 0: SP	1: E(* 2) 0: L(* 2)						
פרסם	Same as [II] 72 ×××× of menu 505.													
0075	1: FE ON	1: DRUM LOCK		0: CAP LOCK(PB)		-		_	Electrical system					
0078	(PB) 1: LP 0: SP	(PB) 1: E(* 2) 0: L(* 2)	1: TAPE END	1: TAPE TOP	_			· 	Tape data					
חר מם	1: MP 0: SP	1: CLOG (※ 4)	1: ME 0: MP	1: REC PROOF					Mechanical switch data					
0075	1: DEW (* 3)	· <u></u> -	1: REC CLOG	1: REC	1: UNLOCK 0: LOCK	1: MECHA SW2 (mode switch)	1: MECHA SW1 (mode switch)	1: MECHA SW0 (mode switch)	Mechanical switch data and electri- cal system					

- * 1 EDIT SEARCH REV alone is "0".
- * 2 E: HIGH BAND mode L: STANDARD mode
- * 3 DEW DETECT FLAG
- * 4 RF output "1": RF signal exists (normal)
 - "0": RF signal does not exist (abnormal).

Address map (3) (Menu 505)

The operation status of the system control circuit on the SS-50/50P board can be checked by operating the external switch or button indicated below.

LCD display

OOdOxx 🔲

e.g. If the indication on the LCD display is "00d2"

Hexadecimal indication

	Û							
Bit	7	6	5	4	3	2	1	0
1 or 0	1	0	0	0	0	0	0	1
Hexadecimal number	8	0	0	0	0	0	0	1
	8				1	VTR POW → O	ÆR S' N	w)

The indication "1" or "0" is displayed by operating an arbitrary switch or button.

"81" will appear if the EJECT button is pressed.

Address (LCD display)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
0040		. —	1: PLAY	1: STOP		-		_
0042	1: EJECT	1: REC (VTR start) KEY	1: REW	1: FF	_	_		1: VTR POWER SW → ON
00d5						1: EDIT SEARCH "REV"	1: EDIT SEARCH "FWD"	_
0048	1: (** 1) ADVANCE			1: SHIFT			1: COUNTER RESET	-
	(DISPLAY) 1: TC 0: COUNTER	1: DF 0: NDF		1: PRESET 0: REGEN	1: R-RUN (* 2)			1: U-BIT 0: TC

* 1 To check the ADVANCE button, press the SHIFT button while DEd8xxDD appears on the LCD display to cause the a part to flash, then check the operation of the ADVANCE button.


* 2 To perform self-diagnosis, this switch must be set to the R-RUN side, hence the bit is always "1".


Address map (4) (Menu 505)

Indicates the operation status of TIME CODE in IC302 of the AU-162/162P board.

e.g. TC mode

LCD display





* 1 In the case of 01E4, ® is "FE".

This means that the unit can enter the TC mode.

Address (LCD display)	WORD	® refers to the following unit when the tape is played back.		Contents
DIEH	0	MODE NUMBER	FE	® is "FE" in the case of this address.
0 188	1	HOUR	3A	
0 168	2	MINUTE	7A	If \(\text{\text{ is the display at}} \) left, TC will not operate
O IEA	3	SECOND	7A	correctly.
O IEC	4	FRAME	3A.	

e.g. U-BIT mode

O IEY×× FB

If data is read correctly, "Fd" will be displayed.

<u>·</u>			a io read ees						
Address (LCD display)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	Display ®
0 184	1	1	1	1	1	1	0	1	₩ 2Fd
	1	1	1	1	1	1	1	0	* 3FE
·	1	1	1	0	1	1	1	0	※ 3EE
	0	0	0	0	. 0	0	0	0	※ 3 00

* 2 Fd normal

* 3 FE, EE, 00: Abnormal

Address map (5) (Menu 505)

Enables the period during which the unit was used to be checked.

Address (LCD display)	Display example	Contents
Period during which the unit is powered (display for less than 10 hours)	Example [] IE' [] × [] F []	This is the total period during which the unit is powered. The example at left indicates that the unit was powered for 1 hour and 15 minutes.
DRUM rotation period (display for less than 10 hours)	Example C C C C S	This is the total period during which the drum rotated. The example at left indicates that the drum head was used for a period of 1 hour and 45 minutes.
O 12'5 Number of loading operations (indication for less than 256 operations)	Example 0 125×× 1	In the example at left, "1" means 16 operations, and "2" means 36 operations. "C" means 12 in hexadecimal notation. Consequently, the number of loading operations is $16+12=28$.

Address map (6) (Menu 505, 507)

VIDEO data: Enables the operation status of IC201 (CXA1207R) on the SS-50/50P board to be checked.

LCD display

0060 .xxxx

Address (LCD display)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
0050	3 NCLP2	Yd	CORRE OFF	- .		_	_	
0062	DOC OFF	CAMERA REC	9 E	8 CFL1	7 CFL2	6 NCL1	5 NCL2	MCLP1
0064	II PB	18 S	II INSEL	III VIDEO AGC	DIS- CHARGE	W CCD	CCIR443	IZ EDIT

Data content

Data content					·	
TICORRE	н	Makes Y correlation pulses always	12EDIT	Н	Edit mode	
OFF	11	LOW.	IZEDI I	L	Normal	
	L	Normal	FROOTD 440	Н	Supports fsc=4.43 MHz	
(A) * * 1	Н	Causes Yd to be played back during PB.	IICCIR443	L	Supports fsc=3.58 MHz	
2Yd	L	Normal		Н	Supports use of two CCD DLs during PB.	
3NCLP2			14W CCD	L	Supports use of one CCD DL during	
4NCLP1		Changes the characteristics of the noise		٠.	PB.	
5NCL2		canceler during PB.	15Discahrge	н	Discharges the external clamping	
6NCL1					capacitor connected to pins 30 and 30.	
		PB Y PB Y Comb Filter Depth stan-		L	Normal	
☑CFL2		dard value	IdVideo AGC	H	Video AGC ON	
		(low range input minute level)	Ed video 71de	L	Video AGC OFF	
		CFL2 CFL1 H L	ZINSEL	H	VIN2 input during REC at pin 3.	
®CFL1		H -10dB -6dB		L	VIN1 input during REC at pin 🕸	
ocre:		L -1.5dB 0dB	570	Н	Supports separation signals during REC.	
9E	H	Supports the Hi8 mode.	13S	т	Supports composite signals during	
(a) [5]	L	Supports the normal mode.		L	REC.	
II Camera	Н	Camera recording mode	กลออ	Н	PB (playback) mode	
REC	L	Video recording mode	19PB	L	REC (recording) mode	
DDOC	Н	Does not perform dropout compensation (D.O.C.).	H=1			
OFF	T	Normal	L=0			


L=0

Normal

Address map (7) (Menu 203)

This menu can be used instead of menu 505 to check the details of abnormalities instantly.

LCD display



		(A)				B			
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0		
1	1	1	1	1	1	1	1		
8	7	6	5	4	3	2			
5 : NO EM	ERGENCY FLA	.G		I: F. MODE=STOP EMERGENCY #1					
TED COTT A D.T.C	OF BARBOORNO	W CODE ET AC		IN DATTED	M. DATTEDY END				

6: CHANGE EMERGENCY CODE FLAG

7: AGING MODE

8: NOT USED

2: BATTERY END

3: TAPE END

4: FUNCTION MODE=STOP EMERGENCY @

1-14. FP-40/40P Board Self Diagnosis


The EVW-300/300P has a self diagnostic function which judges whether the switches and LCD display on the FP-40/40P board are functioning correctly.

Operation method


- 1. Connect TP501 and GND (E1) on the FP-40/40P board with a shorting clip.
- Install the side plate (right) assembly on the unit, and switch the power ON. (The unit will enter the selfdiagnostic mode.)
- 3. Check the LCD display visually.

(LCD screen)

ullet The time code will be displayed in sequence from 0 to F.



Characters are displayed in the sequence PB → VITC
 → NDF → SLAVE → 2FLD → HOLD.



• The warning cursor corresponding to the display at the bottom of the LCD display (RF, SERVO, HUMID, SLACK, TAPE END, BATT) flashes in sequence from the left.



The cursor corresponding to each display moves progressively from the left.

- The WARNING lamp will light.
- The LCD display changes from all lit → all out → all lit, then self diagnosis of each switch starts.

- 4. If the indication of the LCD display corresponding to each switch changes when a switch on the operation panel is operated, that switch is functioning correctly. The relation between each switch and the state of the LCD display is shown in the table below.
 - e.g. Changes from 0 to 1 with SHIFT button pressed

e.g. This cursor flashes with DISPLAY switch turned on-

		Item that can be
No.	Diagnostic item	confirmed
1	F-RUN key	
2	R-RUN key	
3	TC/U-BIT switch	
4	Not used	
5	ADVANCE button	
6	SHIFT button	
7	REGEN/RESET switch	
8	COUNTER RESET button	AVTEST (EE switchover)
9	DISPLAY switch	AUDIO MUTE
10	DF/NDF switch	WARNING LAMP
11	TEST	VAPB MODE
12	RF SWP	EJECT button
13	REMOTE REC	SP/LP
14	Not used	

1-15. BATTERY END/NEAR END VOLTAGE SETTING

It is necessary to set the BATTERY END/NEAR END voltages after replacing the SS-50/50P board or replacing IC108 on the SS-50/50P board.

According to use, the desired voltage can be set within the settable range.

Settable range: 7.5 V to 12.5 V

Settable unit: 0.02 V

Factory settings: Battery end voltage 10.98 V


Battery near end voltage 11.30 V

Equipment required: DC power supply, digital voltmeter

- 1. Connect the DC power supply to the unit. (Fig. 1)
- 2. Connect TP502 and GND (E1) on the FP-40/40P board with a shorting clip.
- 3. Load a blank tape, then press the [VTR] button on the front panel to enter the REC mode.
- 4. Refer to section 1-10, then select menu "503" when performing the battery end voltage setting, or menu "504" when performing the battery near end voltage setting.
- 5. Set the [R-RUN/SET/F-RUN] switch to the R-RUN position.
- Place the ends of the leads of the digital voltmeter on the pins of the DC IN connector, as shown in the Fig. 2, then adjust the DC power supply until the desired voltage is obtained.

Note: Take great care that the leads do not touch any other pins.

- 7. Press the [COUNTER RESET] button.
 (The LCD display will be out while the set value is being written to the ROM.)
- 8. Stop the REC mode.
- 9. Set the [SELF DIAG] switch to OFF, then turn the power OFF momentarily.



1-16. REC PAUSE POSITION ADJUSTMENT

You can use the SELF DIAG mode to adjust the REC PAUSE position if picture disturbance occurs at back space edit position of the played-back picture. Perform this adjustment only when picture disturbance is noticeable. Do not perform the adjustment during normal servicing.

- 1. Connect TP502 and GND (E1) on the FP-40/40P board with a shorting clip.
- 2. Select menu "204" according to section 1-10.
- 3. Set the [R-RUN/SET/F-RUN] switch to the [R-RUN] position, then vary the data.

Variable range: E0~E8~F0~F8~00

Factory setting: F0

- 4. Load a blank tape, then press [VTR] on the front panel to enter the REC mode. Pressing the [VTR] button once again will cause the unit to pause. Repeat this operation several times, waiting for at least 10 seconds between each operation.
- 5. Review the recording, and check the back space edit point with the monitor.
- 6. Repeat steps 3 to 5, and change the data in menu "204" so that the skew becomes minimum.
- Press the [COUNTER RESET] button.
 (The LCD display will be out while the set value is being written to the ROM.)
- 8. Set the [SELF DIAG] switch to OFF, then turn off the power momentarily.

1-17. NOTE ON SS-50/50P REPLACEMENT

It is necessary to perform the following settings after replacing the SS-50/50P board, or repacing the IC108 on the SS-50/50P board. For details, refer to section 1-13.

- 1. Select menu "501" and select data "11" to set the default values of the battery end/near end voltage, lithium battery end voltage and switching position.
- 2. Select menu "503" and set the battery end voltage.
- 3. Select menu "504" and set the battery near end voltage.
- 4. Select menu "101" and perform the switching position adjustment.

1-18. BOARD SWITCH SETTINGS

ES-4/4P board

• S1 (VTR TEST)

Switch over the Y signal output to the VTR.

Up: The Y signal will be output.

Down: The VBS signal will be output.


The factory setting is the up position.


IE-33 board

• S1 (75% CB/100% CB) (NTSC only)

Up: White level 77% color bar signals are output. Down: White level 100% color signals are output.

The factory setting is 75% CB (up position).





1-38

AT-70 board

• S1 (FRAME RESET/FIELD)

The CCD readout method can be set to either frame reset readout (EVS) or field readout.

The factory setting is FLD (up position).

• S2 (FULL FUNCTION/OPE)

Up (OPE): Normal mode Down (FULL FUNCTION):

In addition to the normal mode, the following modes can be varied.

- Control setting of the video system (* 1)
- · Auto iris setting

(*2)

· Gain, clear scan setting


(* 3)

· AGC, AE speed select setting


(* 4)

By setting this switch to the [FULL FUNC] side in the case of an AUTO WHITE or AUTO BLACK error, the details of the error can be seen. (* 5)

The factory setting is OPE (up position).



- * 1 Changing the control setting mode of the video system
- 1) Set S4 of the AT-70 board to [OPE] (up position), and S2 to [FULL FUNC] (down position).
- 2) By setting the [DISP CHG] switch on the side of the unit, the following screen will be displayed on the VF screen after the normal control mode.
 - ↓ : Push down the [DISP CHG] switch.
 - 1: Push up the [DISP CHG] switch.



From this screen, the control voltage corresponding to the item indicated by the flashing arrow $[\rightarrow]$ can be varied using the [UP] or [DOWN] switch on the front of the unit.

Standard setting: 00

Variable range: 0 V \sim 2.5 V \sim 5.0 V (display $-99\sim$ 00 \sim 99)


Display	Control item	Voltage change point	Memory	Renewal of set data
R GAIN R gain		PR-159/159P board; pin 7 of IC13	× Canceling control with	The data will be renewed in the AUTO
B GAIN	B gain PR-159/159P the [W.BAL] switch × of IC13		WHITE mode.	
R PED	R pedstal	PR-159/159P board; pin 8 of IC13	0 .	The data will be renewed in the AUTO
B PED	B pedstal	PR-159/159P board; pin 12 of IC13	0	BLACK mode.
GAMMA	gamma	PR-159/159P board; pin 2 of IC13	0	
KNEE	knee point	PR-159/159P board; pin 3 of IC13	0	
W. CLIP	white clip	PR-159/159P board; pin 4 of IC13	0	
CRISP A	aperture crispening	AT-70 board; pin 3 of IC13	0	
CRISP D	detail crispening	PR-159/159P board; pin 19 of IC13	× Canceling control with the [GAIN] switch	The data will be renewed with the [GAIN] switch.
P KNEE	pre-knee point	PR-159/159P board; pin 6 of IC13	0	

Return to the standard setting of 00 after changing the control voltage.

* 2 Changing the auto iris setting mode

- ↓: Press down the [DISP CHG] switch.
- ↑: Press up the [DISP CHG] switch.

Change the data with the [UP] switch or the [DOWN] switch.



(To the gain and clear scan setting mode)

Last page of the video system control mode

The AVERAGE/PEAK ratio of the AUTO IRIS, AGC and AE level detection can be changed.

Standard setting: 03/07

Setting of AUTO IRIS, AGC and AE convergence level

AUTO IRIS loop gain setting

Standard setting: 00


Note: If the gain is increased excessively, the iris may hunt when a bright subject is shot.

* 3 Changing the gain and clear scan setting modes

↓: Press down the [DISP CHG] switch.

1: Press up the [DISP CHG] switch.

Change the data with the [UP] switch or the [DOWN] switch.



(To the AGC and AE speed select modes)

Last page of the auto iris setting mode

The upper limit of the gain which can be set with the [GAIN] switch on the side of the unit can be varied.

Variable range: 2 dB to 24 dB (1 dB steps)

Standard setting: 18 dB

The upper limit of the frequency which can be set using a clear scan function can be varied.

Variable range: 59.9 to 10169 Hz


Standard setting: 200.3 Hz

• You can enter the low speed shutter mode by pressing the [UP] switch while the screen shown at left is displayed.

LOW SHT: 002FLD

Variable range: 002FLD to 510FLD (2FLD steps)

- * 4 Changing the AGC and AE speed select setting modes
 - \downarrow : Press down the [DISP CHG] switch.
 - ↑: Press up the [DISP CHG] switch.



Last page of the gain and clear scan setting modes

AGC speed (loop gain) setting By increasing the value, the loop gain will rise.

Variable range: −99~00~99

Standard setting: 00

AE speed (loop gain) setting By increasing the value, the loop gain will rise.


Variable range: −99~00~99

Standard setting: 00


Note: If the loop gain of AGC and AE is increased excessively, the AGC may hunt when a bright subject is shot.

* 5 AUTO WHITE and AUTO BLACK error messages


• AUTO WHITE error message



S2/AT-70 → FULL FUNC position



• AUTO BLACK error message



Note: Return S2/AT-70 to OPE position after using this mode.

Error display when there is a defect in the circuit (normal mode)

① R : R-ch error : B-ch error В

> : G-G reference voltage A/D error G-G

② CONTROL: Control circuit error

(Microprocessor → D/A converter →

Each video circuit)

DETECT : Detection circuit error

(PR output → Detection circuit in AT board → Microprocessor)

Error message when there is a defect in the circuit (normal mode)

R : R-ch error G : G-ch error : B-ch error В

> : G-G reference voltage A/D error G-G

: DARK CONT (black tracking) error DARK PED : PED CONT (black balance) error

ADJUST : Outside the adjustment range CONTROL: Control circuit error

(Microprocessor → D/A converter →

Each video circuit)

: Detection circuit error DETECT

> (PR output → Detection circuit in AT board → Microprocessor)

• S3 (OPE → KNEE HI)

Up (OPE): Normal mode

Down (KNEE HI): Mode which clears the KNEE, PRE KNEE and WHITE CLIP in the

ADJ MODE


The factory setting is OPE (up position).

1) Set S4 on the AT-70 board to ADJ (bottom position), and S3 to KNEE HI (bottom position).

2) Cancel KNEE, PRE KNEE and WHITE CLIP using the [UP] switch or the [DOWN] switch.

↓: Press the [UP] switch.

1: Press the [DOWN] switch.



NORM:

Normal state

OFF: Cancel

• S4 (ADJ/OPE)

Up (OPE): Normal mode

Down (ADJ): Control data of the following items is

preset.

R/B GAIN, R/B PEDESTAL, MASTER PEDESTAL, DETAIL

The memory data can be cleared by using this switch (* 6).

The factory setting is OPE (up position).

- * 6 The following data memorized in the unit can be changed back to the factory settings.
 - · AUTO WHITE data
 - · AUTO BLACK data
 - The following data set using the [UP]/[DOWN] switch

AUTO IRIS OVERRIDE
DETAIL
MASTER PEDESTAL
SHUTTER, CLEAR SCAN
AE ON/OFF
LOW LIGHT IND ON/OFF
AUTO IRIS mode
SHUTTER display mode


GAIN UP switch select

Changeover point between AGC • AE and AUTO IRIS

- 1) Set S4 on the AT-70 board to ADJ (bottom position).
- 2) Press down the [DISP CHG] switch.

• ERASE?

By pressing the [UP] switch, the entire contents of the memory will be erased.



4) Finally, be sure to return S4 on the AT-70 board to OPE (up position).

VO-43/43P board

• S801 (CHROMA MUTE)

Left (OPE): Normal mode

Right (CHROMA MUTE): The chroma signal is muted.


Set this switch to CHROMA MUTE (right side) during Y/C SEP adjustment or IR adjustment.

The factory setting is OPE (left side).


MB-381/381P board

•S1 (TEST/OPE)

This switch is not used. Set it to the OPE (up position).




VO-43 BOARD (COMPONENT SIDE)





MB-381 BOARD (COMPONENT SIDE)

1-19. SYSTEM CONFIGURATION




EVW-300 (UC)






CN1-B18 BARS side







	Adjustment Item	Initial Setting	Test Point	Adj. Point	Specification	Remarks	
Step 1	Carrier Balance	GAIN switch → 0dB OUTPUT switch → BARS	Vectorscope screen	• RV12/ES-4 • RV13/ES-4	Locate black beam spot in the center of screen		
	0.1 D ===================================	OU I PU I SWITCH → BAKS	Di- 420/E +	-	0.75±0.01V	S1/IE-33 → 75%	
Step 2	Color Bar 75%/100%		Pin A19/Extension board (IE-33)	RV16/IE-33	1.00±0.01V	S1/IE-33 → 100%	
0. 0	0.4 11		Waveform monitor	-	7.5±0.5 IRE	31/1E-33 → 100%	
Step 3	Setup Level		screen	ORV4/ES-4	77±2 IRE		
Step 4	Gray Level	· 		• RV3/ES-4 • RV5/ES-4	40±2 IRE		
Step 5 Step 6	SYNC Level CB Carrier leakage		-	RV1/PR-159	Minimize white carrier leakage		
Step 0		:	·	O RV2/PR-159	· · · · · · · · · · · · · · · · · · ·		
Step 7	Burst Level		Vectorscope screen	● RV8/ES-4	Burst → 75% position		
Step 8	Burst Phase			RV9/ES-4 PHASE knob/ Vectorscope	Burst → 75% axis	-	
Step 9	Color Vector			O LV1/ES-4 O RV10/ES-4 O RV14/ES-4	Locate beam spot of each color in the specified frame \boxplus .		
Step 10	1H OUT balance	Object: Burst chart	TP8/IE-33	● RV7/IE-33	Waveforms are not doubled.		
Step 11	2H OUT balance	Lens iris → 0.5MHz LEVEL: 100 IRE	TP9/IE-33	⊘ RV9/IE-33		-	
Step 12	1H Gain	Object: Gray scale chart OUTPUT switch → CAM WHITE MODE switch → PRE Lens iris → VIDEO OUT LEVEL: 100 IRE	CH1: TP7/IE-33 CH2: TP8/IE-33	⊘ RV8/IE-33	Waveform is flat.	Set the gain for CH1 and CH2 the same level. Set the GAIN ADD mode for CH1 and INVERT mode for CH2.	
Step 13	2H Gain		CH1: TP7/IE-33 CH2: TP9/IE-33	● RV10/IE-33	Waveform is flat.	Set the gain for CH1 and CH2 to the same level. Set the GAIN ADD mode for CH1 and INVERT mode for CH2.	
Step 14	G/B/R input gain	Object: Gray scale chart	TP4/IE-33		White level: 115±5mV · ·		
		Lens iris →	TP2/IE-33	⊘ RV1/IE-33			
		Level at TP3/IE-33: 260mV	TP6/IE-33	⊘ RV3/IE-33			
Step 15	G GAIN/GAMMA/PED	Lens iris →	Pin B21/Extension	⊘ RV13/PR-159	Pedestal level 25±2mV	Cap the lens See	
		Level at A26/Extension board	board (PR-159)	⊘ RV6/PR-159	Cross point level 550±20mV	Uncap the lens *	
		(PR-159): 115mV		⊘ RV16/PR-159	White level: 1000±10mV		
Step 16	R/B GAIN/PED	Lens iris → Leave the lens iris as it was set in	Waveform monitor	● RV12/PR-159 ● RV14/PR-159	Minimize the carrier leakage at pedestal level.	Repeat the adjustments.	
		step 15, and cap the lens.		© RV15/PR-159 © RV17/PR-159	Minimize the carrier leakage at white level.		
Step 17	G black set and pedestal	Close the lens iris	Pin B21/Extension board (PR-159)	○ RV5/IE-33	Repeat the adjustments until the level does not change even if the gain switch is set to either 0dB or HIGH (18dB).		
		GAIN switch → 0dB		● RV13/PR-159	Pedestal level 25±2mV		
Step 18	R/B black set and pedes- tal	Close the lens iris GAIN switch → HIGH (18dB)	Vectorscope screen GAIN: MAX	✓ RV4/IE-33✓ RV6/IE-33	Locate black beam spot in the center of screen.	Repeat the adjustments until the level does not change even if the	
		Close the lens iris GAIN switch → 0dB		● RV12/PR-159 ● RV14/PR-159	Locate black beam spot in the center of screen.	gain switch is set to either 0di or HIGH (18dB).	
Step 19	Knee compensation	Lens iris → Pin B21/Extension board (PR-159): 1020 +10 mV -0 · · ·	Pin B21/Extension board (PR-159)	⊘ RV7/PR-159	White level: 1000 +0 mV -10	Object: Gray scale chart	
Step 20	Pre-knee	Object: Gray scale chart Lens iris →	Pin B21/Extension board (PR-159)	ORV10/PR-159	White level: 1150 +20 mV -0		
		Level at pin A26/Extension board (PR-159): 350mV	Waveform monitor screen	● RV9/PR-159 ● RV11/PR-159	Minimize the carrier leakage at level of up to the third step from the top		
Step 21	PR WHITE CLIP	GAIN switch → HIGH (18dB)	Pin B21/Extension board (PR-159)	● RV8/PR-159	White level: 1150±10mV	Object: Gray scale chart	
Step 22	ES WHITE CLIP	Lens iris → VIDEO OUT LEVEL: 110±2 IRE	Waveform monitor screen	● RV6/ES-4	Maximum level 125 +0 IRE -2	Object: Burst chart GAIN switch → 0dB	

* 1: Align the pedestal, cross point, and white levels repeatedly.







SECTION 2 PERIODIC CHECK AND MAINTENANCE

The following periodic check and maintenance schedule are recommended to be performed in order to maintain performance and obtain longer life of the unit. The period of the check and maintenance refers to Hours Meter on Side Panel.

2-1. MAINTENANCE AFTER REPAIRS

Perform the following maintenance after repairs without regarding operational hours of the unit.

2-1-1. Cleaning of Rotary Upper Drum

Press cleaning piece moistened with cleaning fluid lightly against Rotary Upper Drum and turn slowly Rotary Upper Drum counterclockwise by a hand.

Note; Never turn it with electric power. Never turn it clockwise by a hand. When cleaning head chip, never move the cleaning piece in vertical direction. It is possible to damage the head chip.

2-1-2. Cleaning of Tape Path System


Put Cassette-up Compartment Assembly into the EJECT mode. Clean tape path system as No. 1 thru. No. 11 Guides, Drum, Capstan Shaft, and Pinch Roller with the cleaning piece moistened with cleaning fluid.

2-1-3. Cleaning of Drive System

Clean drive system as Reel Table surface and belt with the cleaning piece moistened with cleaning fluid.

2-2. PERIODIC CHECK

Perform periodic check and maintenance according to operational hours of the unit.



2-3. HOURS METER

Hours Meter can be displayed the total rotation time of the Upper Drum Assembly on the LCD display on the Side Panel. It is recommended that the Hours Meter is used as a tool for determining the periodic check.

Operation Procedures

- 1. Set the [DISPLAY] switch on the Side Panel to [TC] position.
- 2. Set the [R-RUN/SET/F-RUN] switch to [F-RUN] position.
- 3. Set the [TC/U-BIT] switch to [U-BIT] position.
- 4. The total rotation time of the Upper Drum Assembly is displayed while pressing the [SHIFT] button.

O : Cleaning	: Replacement	♦: Check	: Apply oil	□: Smear grease
O. Creaming	• itcpiacement	V. Oncon	m · libbil on	Offical greate

Location		Hours of Use (H): Hour of Drum Rotation							Reference				
	Part Name	Part No.	500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	Section
Tape Path	Tape Path surface		0	0	0	0	0	0	0	0	0	0	2-1.
	Upper Drum Assembly (DGR-66-R)	A-7049-312-A	0	•	0	•	0	• .	. 0	•	0	•	3-15.
	Lower Drum Assembly (DGR-66A-R)	A-7048-362-A	0	0	0	0	0	•	0	. 0	0	0	3-15.
	Pinch Roller Assembly	A-7040-219-A	0	0	0	0	0	•	0	0	0	0	3-8.
	(*1) Coaster (Left) Assembly	A-7040-204-A											2-4. 3-21.
	(*1) Coaster (Right) Assembly	A-7040-216-A											2-4. 3-20.
	(*2) Capstan Motor	8-835-331-31						•		•			2-5. 3-3.
	Loading Motor	A-7040-208-A	-					•					3-22.
	(*2) Joint Gear Assembly	X-3726-805-1											2-5. 3-17.
	TS Brake Assembly	X-3726-808-3				•				•			3-18.
	Tension Regulator Band Assembly	X-3728-859-1				•			4	•			3-12.
	(*2) Relay Pulley Assembly	X-3726-813-4											2-5. 3-18.
em	(*1) (*2) Drive Gear (Left) Assembly	X-3728-842-1		·	:	□/■				/ ■			2-4. 2-5. 3-21.
re System	(*1) (*2) Drive Gear (Right) Assembly	X-3728-843-1				□/■				□/■			2-4. 2-5. 3-20.
Drive	S Reel Table Assembly	X-3728-851-1	0	0	0	0	0	•	0	0	0	0	3-10.
	T Reel Table Assembly	X-3728-855-6	0	0	0	0	0	•	0	0	0	0	3-11.
	(*2) RC Gear Assembly	X-3728-858-2								-			2-5. 3-17.
	(*1) Worm Assembly	X-3940-276-2											2-4. 3-22.
	Timing Belt (S)	3-728-866-11				•				•			3-17.
	Timing Belt (L)	3-741-197-01				•				•			3-17.
	(*1) Groove of Coaster Guide												2-5.
e)	Abnormal-noise		\Q	\Diamond	♦	\Diamond	\Diamond	\Diamond	\Diamond	. ♦	\Diamond	\Diamond	
Performance Check	FWD Back Tension Measurement			♦		\langle		\$		\rightarrow		♦	4-1.
Perfe Chec	FWD, RVS Torque Measurement	· ·		♦		♦		♦		\$		♦	4-2.

^(*1) Smear a grease referring to Section 2-4.

^(*2) Apply oil referring to Section 2-5.

^(*3) When overhauling, replace part referring to the list.

^(*4) Replacement of part will be influenced by operating surroundings.


^(*5) When repairing, be sure to clean Tape Path surface.

2-4. SMEAR GREASE

Smear a grease periodically to the following portions.

- · Top projection of Coaster (Left) Assembly.
- · Top projection of Coaster (Right) Assembly.
- · Coaster Guide's groove of mechanical chassis.
- Sliding surface of the Coaster Guide on the mechanical chassis.
- Lever Drive's groove of Drive Gear (Left) Assembly.
- Lever Drive's groove of Drive Gear (Right) Assembly.
- · Worm Gear of Worm Assembly.

Then smear a grease to the shaded portions and arrow portions.




2-5. APPLY OIL

Apply oil periodically to the following portions.

- · Capstan Shaft.
- · Shaft of Drive Gear (Left) Assembly.
- · Shaft of Drive Gear (Right) Assembly.
- Shaft of Idler Pulley Assembly.
- · Shaft of RC Gear Assembly.
- · Shaft of Connecting Gear Assembly.

Then apply a half drop of oil to the arrow portions.



2-6. HOW TO USE CLEANING TAPE

Cleaning tape: V8-6CLHSP

(supplied accessory) V8-25CLH (option)

Note: Do not use cleaning tape, V8-25CLN.

(1) When Rotary Head clogs and the head clogging cannot remove with head cleaning, use the cleaning tape. If using in other conditions, it will be shorten the life of the head.

(2) Use within fifteen seconds for a cleaning and never rewind the cleaning tape for use. The cleaning tape can only once be used.

2-7. OTHERS

(1) Sony oil

 Be sure to use Sony oil. If other oil is used, it is possible to trouble because of different viscosity.


Sony oil: Part No. 7-661-018-18

- Use Sony oil in which dust and others are not mixed. If mixed, the bearing may seize or wear.
- A drop of oil means the amount which sticks to a 2mm-diameter rod as shown in the figure.

(2) Sony grease

• Be sure to use Sony grease.

Sony grease: Part No. 7-662-010-08 (SGL-701)



SECTION 3 REPLACEMENT OF MAJOR PART

PREPARATION FOR REPLACEMENT OF PART


Replacement of some parts use a Mode Selector (Tool). _____ marked modes in the replacement procedure are set by pressing button on the Mode Selector. Install a Mode Selector III Panel on the Mode Selector and then use it.

Mode Selector: J-6080-825-A


Mode Selector III Panel: J-6082-023-A

Operation of Mode Selector

- 1. Location of part and control (Fig. 1)
- 2. Connection (Fig. 2)
- (1) Install the Mode Selector III Panel on the Mode Selector.
- (2) Connect the Mode Selector III Conversion Connector to the 6P connector (white) of the Mode Selector M-switch.
- (3) Remove the Mechanical Deck Block referring to Section 1-2-1.
- (4) Install the FP-89 Board to the Mode Selector III Conversion Connector.
- (5) Touch the clips (black, red) of the Mode Selector III to terminals of the Loading Motor.



- 3. Operation (Fig. 3)
 - · Use only M-mode select buttons.
 - Refer to the uppermost display on the Mode Selector III Panel about display of the mode.
 The display of IA, IB and IC light up during the mode changes.
 - Press continuously the right side M-mode select button and the mode changes the EJECT, (IA), ULD, (IB), STOP, (IC) and FWD in order.
 - Press the left side M-mode select button, mode changes from FWD to EJECT in order.





3-1. REPLACEMENT OF HC ROLLER ASSEMBLY

Removal:

- (1) Remove the Cassette Lid and Side Panel (Left) Assembly referring to Section 1-1.
- (2) Remove a fixing screw and remove the IC SBX1508-41.
- (3) Remove a fixing screw and remove HC Roller Assembly.

- (1) Put the two projections of the HC Roller Assembly into the two holes of the mechanical chassis.
- (2) Install the HC Roller Guide with the fixing
- (3) Install the IC SBX1508-41 with the fixing screw.






3-2. REPLACEMENT OF GUIDE GUARD ASSEMBLY

Removal:

- (1) Remove the Cassette Lid and Side Panel (Left) Assembly referring to Section 1-1.
- (2) Remove a fixing screw and remove Guide Guard Assembly.

- (1) Put a projection of the Guide Guard Assembly into the hole.
- (2) Install the Guide Guard Assembly with the fixing screw.




3-3. REPLACEMENT OF DC MOTOR (CAPSTAN MOTOR)

Tool: Mode Selector

Removal:

- When replacement, be careful not to touch capstan motor shaft, oil seal and rotor.
- (1) Remove the Mechanical Deck Block referring to Section 1-2.
- (2) Remove SS-50 Board referring to Section 1-2-3.
- (3) Set ULD mode.
- (4) Remove two fixing screws and remove the MD Frame C.
- (5) Remove the HC Roller Assembly referring to Section 3-1.
- (6) Turn the stopper in the direction of arrow A as far as it will go.
- (7) Remove two fixing screws. Move Capstan Motor in the direction of the arrow and remove it while paying attention not to touch the projection of the chassis. (Fig. A)

- (1) Move the Capstan Motor in the opposite direction of the arrow and install it in the hole of the chassis. (Fig. A)
- (2) Put the two projections of the Capstan Motor to the holes of the fixing screw. Engage the gear portion of the Capstan Motor to Connecting Gear. Be careful not to damage the gear.
- (3) Install the Capstan Motor with two fixing screws. Check that there is no clearance between the Capstan Motor and chassis.
- (4) Turn the stopper in the direction of arrow B as far as it will go.



3-4. REPLACEMENT OF S AND T BRAKES


Removal:

- (1) Remove the Side Panel (Left) Assembly referring to Section 1-1.
- (2) Remove tortion spring (ST).
- (3) Remove Shaft Holding Pin A and remove T Brake.
- (4) Remove Shaft Holding Pin B and remove S Brake.

Installation:

- (1) While putting the gear portion to the notch, install the S Brake.
- (2) Install the Shaft Holding Pin B.
- (3) Put the shaft A of the T Brake to the left side of the Brake Release Arm as shown in the figure and install the T Brake.
- (4) Install the Shaft Holding Pin A.
- (5) Put the torsion spring (ST) under the claw A of the shaft B and hook each ends of spring to the claws B.

Note: Before assembling the S and T Brakes, check that the claws of the Shaft Holding Pins A and B are not broken.



3-5

3-5. REPLACEMENT OF LB BRAKE AND SHAFT HOLDING PIN


Removal:

- (1) Remove the Side Panel (Left) Assembly referring to Section 1-1.
- (2) Remove a fixing screw and remove TL Stopper Plate.
- (3) Remove Shaft Holding Pin A and remove LB
- (4) Remove Shaft Holding Pin B and remove LB Lever.

Installation:

- (1) Install the LB Lever so that the hole of the LB Lever fits to the pin of the LB Gear, and fasten with the Shaft Holding Pin B.
- (2) Put the pin of the LB Brake into the notch of the LB Lever. While putting the gear portion of the LB Brake into the notch A as shown in the figure, install the LB Brake.
- (3) Install the Shaft Holding Pin A.
- (4) Put the projection of the TL Stopper Plate to the hole, and install with the fixing screw.

Note: Before assembling the LB Brake and Shaft Holding Pins, check that the claws of the Shaft Holding Pins A and B are not broken.



EVW-300 (UC)

3-6


3-6. REPLACEMENT OF LB RELEASE ARM

Removal:

- (1) Remove the Cassette-up Compartment referring to Section 1-3.
- (2) While pushing claw in the direction of the arrow from top of the unit with a thin flatblade screwdriver, remove LB Release Arm.

Installation:

(1) Put the LB Release Arm to the shaft. Put the A, B, C and D points into the three holes and lock the LB Release Arm with the claw.




3-7. REPLACEMENT OF RK STOPPER AND STOPPER ARM

Removal:

- (1) Remove the Cassette-up Compartment referring to Section 1-3.
- (2) Remove torsion spring (RK).
- (3) Release claw of the chassis in the direction of the arrow and remove RK Stopper Arm.
- (4) Remove RK Stopper.

- (1) Install the RK Stopper to the shaft A.
- (2) Install the RK Stopper Arm to the shaft B. Through the pin of the RK Stopper into the hole A of the RK Stopper Arm and lock the RK Stopper Arm with the claw of the chassis to the hole B.
- (3) Put the torsion spring (RK) to the shaft of the RK Stopper and hook the ends of it to the claws A and B.



3-8. REPLACEMENT OF PINCH ARM ASSEMBLY AND TG-7 ARM ASSEMBLY

Tool: Mode Selector Sony Oil

Sony Grease


Removal:

- (1) Remove the Cassette-up Compartment referring to Section 1-3.
- (2) Move that TG-7 Arm Assembly in order to be placed as shown in fig. A with Mode Selector.
- (3) Remove a stopper washer and remove Pinch Arm Assembly.
- (4) Bend the claw in the hole A in the direction of the arrow with a thin flatblade screwdriver and remove TG-7 Plate Spring.
- (5) Remove TG-7 Arm Assembly.

Installation:

- Smear a grease to inside edge and bottom of the hole B.
- (2) Put the pin of the longitudinal hole on the chassis to the groove of the TG-7 Arm Assembly and put the shaft into the hole B.
- (3) Smear a grease to the shaded portion A of the TG-7 Arm Assembly. Be careful not to smear a grease to the fixing screw of the TG-7 Arm Assembly. (Fig. B)
- (4) Put the TG-7 Plate Spring into the hole A. Lock the claw and install it.
- (5) Apply a half drop of oil to the shaft A. (Fig. C)
- (6) Put the Pinch Arm Assembly in the shaft A and put the C portion of the Pinch Sub Arm Assembly into the B portion. When putting the Pinch Arm Assembly into the shaft A, be careful not to touch the TG-7 Guide and rubber portion.
- (7) Fasten the stopper washer.

Note: After replacement, perform the Tape Path Adjustment referring to Section 5.



3-9. REPLACEMENT OF TG-2 ASSEMBLY


Removal:

- (1) Remove the Cassette Lid and Side Panel (Left) Assembly referring to Section 1-1.
- (2) Turn the arrow portion counterclockwise and remove TG-2 Upper Flange.
- (3) Remove TG-2 Roller, TG-2 Sleeve and TG-2 Lower Flange and a compression spring.

Installation:

- (1) Install the compression spring, TG-2 Lower Flange, TG-2 Sleeve and TG-2 Roller to the shaft.
- (2) Turn the TG-2 Upper Flange about 4 to 6 turns and install it to the shaft. After installation, perform the TG-2 Upper Flange Height Preset.
 - Turn the TG-2 Upper Flange and adjust the height of TG-2 as shown in the figure.

Note: After replacement, perform the Tape Path Adjustment referring to Section 5.



3-10. REPLACEMENT OF S REEL TABLE ASSEMBLY


Tool: Sony Oil
Cassette Tape
Torque Cassette

Removal:

- (1) Remove the S Brake referring to Section 3-4.
- (2) Remove the Tension Regulator Band Assembly referring to Section 3-12.
- (3) Remove S Reel Table Assembly.

Installation:

- (1) Apply a half drop of oil on the top of shaft A. (Fig. A)
- (2) Move RK Gear in the direction of the arrow F. Move UL Brake in the direction of the arrow G. Move LB Brake in the direction of the arrow H.
- (3) Install the S Reel Table Assembly to the shaft $^{\Lambda}$
- (4) Assemble the parts with removal steps (1) to (4) in reverse order.
- (5) Adjust the Tension Regulator FWD Portion referring to Section 3-13.
- (6) Perform the FWD Back Tension Adjustment referring to Section 4-1.



3-11. REPLACEMENT OF REEL TABLE ASSEMBLY

Tool: Sony Oil

Removal:

- (1) Remove the T Brake referring to Section 3-4.
- (2) Turn stopper about 90 degrees in the direction of the arrow A.
- (3) Move LB Release Arm in the direction of the arrow B and remove T Reel Table Assembly.

Installation:

- Apply a half drop of oil on the top of shaft B.
 (Fig. B)
- (2) Move RK Gear in the direction of the arrow C. Move TS Brake in the direction of the arrow D.
- (3) Move LB Release Arm in the direction of the arrow B and install the T Reel Table Assembly EVW-300 (UC)

to the shaft B.

- (4) Turn the stopper in the direction of the arrow E as far as it will go.
- (5) Assemble the T Brake referring to Section 3-4.


3-12. REPLACEMENT OF TENSION REGULATOR BAND ASSEMBLY AND TENSION REGULATOR ARM ASSEMBLY

Tool: Sony Oil
Cassette Tape
Torque Cassette

Removal:

- (1) Remove the SS-50 Board referring to Section 1-2-3.
- (2) Remove the Cassette-up Compartment referring to Section 1-3.
- (3) Remove the TL Holder Plate referring to Section 4-5.
- (4) Remove a fixing screw.
- (5) Remove Tension Regulator Band Assembly from the shaft of Tension Regulator Arm Assembly with a thin flatblade screwdriver. Be careful not to damage the Tension Regulator Band and touch the felt portion of it.
- (6) Remove a tension spring.
- (7) Remove stopper washer from the back of mechanical chassis. Remove Tension Regulator Arm Assembly.
- (8) Release claw and remove Adjust Arm.

- (1) Engage the Adjust Arm so that the claw can be locked as shown in figure A.
- (2) Apply a half drop of oil to the fixing hole of the Tension Regulator Arm Assembly.
- (3) Install Tension Regulator Arm Assembly so that the A portion is positioned in the side of arrow A from Switch Lever Assembly. (Fig. B)



- (4) Hold the Tension Regulator Arm Assembly and install it with the stopper washer from the back of the mechanical chassis.
- (5) Hook the R hook side of the tension spring to the Adjust Arm as shown in the figure. Hook the opposite side of the tension spring to the Tension Regulator Arm Assembly.
- (6) Install the Tension Regulator Band Assembly to the shaft of the Tension Regulator Arm Assembly so that the felt portion goes along the shaded portion of S Reel Table Assembly. Be careful not to damage the Tension Regulator Band Assembly and touch the felt portion.
- (7) Install Tension Regulator Plate portion of the Tension Regulator Band Assembly to the projection of the mecanical chassis and thread the fixing screw but do not tighten.
- (8) Install the TL Holder Plate referring to Section 3-5.
- (9) Assemble the parts with removal steps (2) to (4) in reverse order.
- (10) Install the Mechanical Deck Block.
- (11) Adjust the Tension Regulator FWD Position referring to Section 3-13.
- (12) Perform the FWD Back Tension Adjustment referring to Section 4-1.


3-13. TENSION REGULATOR FWD POSITION PRESET

Tool: Cassette Tape

Removal:

- (1) Remove the Cassette Lid and Side Panel (Left) Assembly referring to Section 1-1.
- (2) Insert a cassette tape and put the unit into the PLAY mode.
- (3) Check that the clearance between A portion of the Tension Regulator Arm Assembly and groove of the chassis is 1.1 ± 0.3 mm. When it is out of the specification, eject the cassette tape and perform the following adjustments.
- (4) Loosen the fixing screw of the Tension Regulator Band Assembly.
- (5) If the clearance more than the specification, move the Tension Regulator Plate in the direction of the arrow A and tighten the fixing screw. If the space is less than the specification, move the Tension Regulator Plate in the direction of the arrow B and tighten the fixing screw.
- (6) Perform steps (2) and (3) again and check that the clearance meets the required specification.

Note: Use a cassette tape which has been advanced half way through minutes.




3-14. REPLACEMENT OF DRUM ASSEMBLY AND CONDENSATION SENSOR

Removal:

- (1) After putting the unit into the EJECT mode, pull out the Mechanical Deck Block referring to Section 1-2.
- (2) Remove the SS-50 Board from the unit referring to Section 1-2-3.
- (3) Remove the Cassette-up Compartment referring to Section 1-3.
- (4) Remove the HC Roller Assembly referring to Section 3-1.
- (5) Remove the Guide Guard Assembly referring to Section 3-2.
- (6) Remove a fixing screw and remove Shaft Ground Terminal.
- (7) Remove the three fixing screws of drum base and remove Drum Assembly with the drum base from the mecanical chassis.
- (8) Remove three fixing screws and remove Drum Assembly from the drum base.
- (9) Disconnect connector of Condensation Sensor from the Loading Motor.
- (10) Remove a fixing screw and remove the Condensation Sensor.

Note: Be careful not to touch the head chip.



Installation:

- Put the A portion of the Condensation Senser into the notch of the mechanical chassis and tighten the fixing screw.
- (2) Connect the connector of the Condensation Sensor to the Loading Motor.
- (3) Pinch the harness of the Condensation Sensor to the Plate SS Assembly's claw of the back of mechanical chassis. (Fig. A)
- (4) Put the Drum Assembly to the two projection of the drum base and tighten three fixing screws.
- (5) Put the drum base to the two projections of the mechanical chassis and tighten three fixing screws.
- (6) Put the Shaft Ground Terminal to the two projections of the mechanical chassis and tighten the fixing screw.
- (7) Install the parts with removal steps (2) to (5) in reverse order.

Note: Be careful not to cut the harness. Be careful not to touch the head chip.

Note: After replacement, perform the Tape Path Adjustment referring to Section 5.

3-15. REPLACEMENT OF ROTARY UPPER DRUM, AND LOWER DRUM

Tool: Rotary Drum Tool
(supplied accessory of Repair Rotary Upper Drum)
L-shaped wrench
(across flat has 1.5 mm)


Removal:

- (1) Remove the Drum Assembly referring to Section 3-14.
- (2) Remove two fixing screws A. (Fig. A)
- (3) Install tool A to the screw hole with two accessory supplied screws. Thread the accessory supplied haxagonal screws into the tool A, and Rotary Upper Drum will move up and can be removed. (Fig. B)

Installation:

- Clean the flange surface and contact surface of the new Rotary Upper Drum. Check that no dust and flaw are left over.
- (2) While adjusting the position of Rotary Upper Drum and positioning hole with tool B, insert the Rotary Upper Drum lightly.
 - Note: At this time, check that the terminals project out from the PC Board of the Rotary Upper Drum. When the terminals are caught, correct them with a pair of tweezers, etc.. (Fig. C)
- (3) Remove tool B and lightly push down the Rotary Upper Drum by hand. If it does not down to the bottom, thread two fixing screws A to the Rotary Upper Drum alternately but do not tighten.
- (4) Insert tool B into the positioning hole and check that it can be inserted smoothly again. If tool B cannot be inserted, loosen two fixing screws A and adjust the position of the Rotary Upper Drum by precision screwdriver etc..
- (5) Tighten two fixing screws A.

Note: After replacemnt, perform the Tape Path Adjustment referring to Section 5.




3-16. REPLACEMENT OF EJECT LEVER, SWITCH LEVER ASSEMBLY AND PINCH SUB ARM ASSEMBLY

Tool: Mode Selector Sony Grease Sony Oil

Removal:

- (1) Remove the Capstan Motor referring to Section 3-3.
- (2) Put the unit into the STOP mode.
- (3) Release claw A and remove Eject Lever.
- (4) Remove stopper washer A and remove Switch Lever Assembly.
- (5) Remove Pinch Load Spring.
- (6) Remove stopper washer B and remove Pinch Sub Arm Assembly.

- (1) Smear a grease to shaft A. (Fig. A)
- (2) While putting the A portion of the Pinch Sub Arm Assembly into the longitudinal hole, put the pin into the notch of the Loading Lever Assembly.
- (3) Fasten stopper washer B.
- (4) Hook the B portion of the Pinch Load Spring between claw B and chassis. Hook the C portion of the Pinch Load Spring to the claw B, and install it.
- (5) Apply a half drop of oil to shaft B. (Fig. B)
- (6) Put the groove of the Switch Lever Assembly to the projection of the Mode Detector Switch and assemble the Switch Lever Assembly to shaft B. Put the pin of the Switch Lever Assembly into the outer groove of Drive Gear (left) Assembly. If the Tension Regulator Arm Assembly is installed, move the pin of the Tension Regulator Arm Assembly in the direction of the arrow A.
- (7) Fasten the stopper washer A.
- (8) Install the Eject Laver and lock claw A.
- (9) After putting the unit into the <u>ULD</u> mode, install the Capstan Motor referring to Section 3-3.




3-17. REPLACEMENT OF TIMING BELT (L), RC GEAR ASSEMBLY, LOADING LEVER ASSEMBLY, TIMING BELT (S) AND CONNECTING GEAR ASSEMBLY

Tool: Mode Selector Sony Oil Sony Grease

Removal:

- (1) Remove the Capstan Motor referring to Section 3-3
- (2) Remove the Pinch Sub Arm Assembly referring to Section 3-16.
- (3) Put the unit into the STOP mode.
- (4) Remove stopper washer A. Remove RC Gear Assembly together with Timing Belt (L) from shaft A.
- (5) Remove the Timing Belt (L) from Idler Pulley Assembly.
- (6) Remove stopper washer B. While pushing LB Release Arm in the direction of arrow A, remove Loading Lever Assembly.
- (7) Turn the stopper about 90 degress in the direction of the arrow B.
- (8) Remove Connecting Gear Assembly together with Timing Belt (S) from shaft B. Be careful not to touch the flange portion. (Fig. D)
- (9) Remove the Timing Belt (S) from the Idler Pulley Assembly.

- (1) Apply a half drop of oil shaft B. (Fig. F)
- (2) Hook the Timing Belt (S) to the Connecting Gear Assembly and hook the opposite side of it to the gear of the Idler Pulley Assembly. (Fig. E)
- (3) Install the Connecting Gear Assembly to shaft B with the Timing Belt (S) hooked on.
- (4) Turn the stopper in the direction of arrow C as far as it will go.
- (5) Apply a half drop of oil on shaft C. (Fig. A)



- (6) Move the LB Release Arm in the direction of arrow A and put the Loading Lever Assembly to shaft C. Put the pin of the Loading Lever Assembly into the groove of Drive Gear (Right) Assembly.
- (7) Fasten the stopper washer B.
- (8) Hook the Timing Belt (L) to the gear of the RC Gear Assembly as shown in figure B and hook the opposite side of it to the gear of the Idler Pulley Assembly. (Fig. E)
- (9) Install the RC Gear Assembly with the Timing Belt (L) on to shaft A. Engage the RC Gear Assembly with the gear of RK Gear Assembly.
- (10) Fasten the stopper washer A.
- (11) Smear a grease to the Loading Lever Assembly as shown in fig. C.
- (12) Install the Pinch Sub Arm Assembly referring to Section 3-16.
- (13) After putting the unit into the ULD mode, install the Capstan Motor referring to Section 3.3


3-18. REPLACEMENT OF IDLER PULLEY, TS BRAKE ASSEMBLY, LB GEAR ASSEMBLY AND RK GEAR ASSEMBLY

Tool: Mode Selector Sony Oil

Removal:

- Remove the Capstan Motor referring to Section 3-3.
- (2) Remove the Switch Lever Assembly referring to Section 3-16.
- (3) Remove the Timing Belt (L), RC Gear Assembly, Loading Lever Assembly, Timing Belt (S) and Connecting Gear Assembly referring to Section 3-17.
- (4) Remove stopper washer A and remove Idler Pulley. Be careful not to touch the flange portion of the Idler Pulley, (Fig. C)
- (5) Release the claw and remove TS Brake Assembly.
- (6) Remove tortion spring (LB).
- (7) Remove stopper washer B and remove LB Gear Assembly.
- (8) Remove RK Gear Assembly.

- (1) Apply a half drop of oil to shaft A. (Fig. A)
- (2) Install the RK Gear Assembly horizontally to the shaft A.
- (3) Apply a half drop of oil to shaft B. (Fig. B)
- (4) Install the LB Gear Assembly to shaft B with stopper washer B.
- (5) Put torsion spring (LB) into shaft C. Hook it to the notch of the mechanical chassis and A portion of the LB Gear Assembly.
- (6) Install the TS Brake Assembly and lock the claw.
- (7) Apply a half drop of oil to shaft D. (Fig. D)
- (8) Install the Idler Pulley to shaft D. Fasten the stopper washer A.
- (9) Install the Timing Belt (L), RC Gear Assembly, Loading Lever Assembly, Timing Belt (S) and Connecting Gear Assembly referring to Section 3-17.
- (10) Install the Switch Lever Assembly referring to 3-16.
- (11) After putting the unit into the ULD mode, install the Capstan Motor referring to Section 3-3.




3-19. REPLACEMENT OF UL GEAR, UL BRAKE, UL ARM AND LB LEAF SPRING

Tool: Sony Oil

Removal:

- (1) Remove the Switch Lever Assembly referring to Section 3-16.
- (2) Remove stopper washer and remove UL Gear.
- (3) Remove UL Arm, 1.6 mm-diameter poly washer and LB Leaf Spring.
- (4) Remove UL Brake.

- (1) Install the UL Brake.
- (2) Apply a half drop of oil to the shaft. (Fig. A)
- (3) Install the LB Leaf Spring to the shaft and fasten it with the 1.6 mm-diameter poly washer as shown in fig. B.
- (4) Install the UL Arm to the shaft so that the projection is put into the groove of the UL Brake
- (5) Install the UL Gear to the shaft. Engage it with the gear of the Drive Gear (Left) Assembly.
- (6) Fasten the stopper washer.
- (7) Install the Switch Lever Assembly referring to Section 3-16.




3-20. REPLACEMENT OF COASTER (RIGHT) ASSEMBLY AND DRIVE GEAR (RIGHT) ASSEMBLY

Tool: Mode Selector Sony Oil Sony Grease

Removal:

- Remove the Capstan Motor referring to Section 3-3.
- (2) Remove the Drum Assembly referring to Section 3-14.
- (3) Remove the Switch Lever Assembly referring to Section 3-16.
- (4) Remove the Timing Belt (L), RC Gear Assembly and Loading Lever Assembly referring to Section 3-17.
- (5) Remove fixing screw A. Remove the Coaster Leaf Spring and Coaster (Right) Assembly.
- (6) Remove two fixing screws B and remove Reinforcement Plate TT.
- (7) Remove the stopper washer 1.5 and remove the Drive Gear (Right) Assembly.

- (1) Smear a grease to the mechanical chassis as shown in fig. A.
- (2) Apply a half drop of oil to shaft A. (Fig. F)
- (3) Smear a grease to pin, shaft and projection of the Coaster (Right) Assembly. (Fig. D)
- (4) Install the pin and shaft of the Coaster (Right) Assembly to the longitudinal hole A of the mechanical chassis.
- (5) Move the Brake Release Arm in the direction of the arrow A.



- (6) Put the A portion of the Drive Gear (Right) Assembly into the B portion and put the hole of it to the pin of the Coaster (Right) Assembly. Install the Drive Gear (Right) Assembly to shaft A. Engage it with Drive Gear (Left) Assembly as shown in fig. B. Check that the Brake Release Arm Assembly is under the gear portion of the Drive Gear Assembly. (Fig. G)
- (7) Fasten the stopper washer 1.5.
- (8) Put the Coaster Leaf Spring to the shaft and pin of the Coaster (Right) Assembly and install it with fixing screw A. At this time, the tightening torque of fixing screw A is about 0.05 N·m {500gf•cm}. If tightened too much, the Coaster (Right) Assembly and Coaster Leaf Spring will be damaged.
- (9) Install the Reinforcement Plate TT to the projection of chassis and tighten the two fixing screws B in order.
- (10) Smear a grease as shown in figures C and F.
- (11) Install the Timing Belt (L), RC Gear Assembly and Loading Lever Assembly referring to Section 3-17.
- (12) Install the Switch Lever Assembly referring to Section 3-16.
- (13) After putting the unit into the ULD mode, install the Drum Assembly referring to Section 3-14.
- (14) Install the Capstan Motor referring to Section 3-3.

Note: After replacement, perform the Tape Path Adjustment referring to Section 5.

3-21. REPLACEMENT OF COASTER (LEFT) ASSEMBLY AND DRIVE GEAR (LEFT) ASSEMBLY

Tool: Mode Selector Sony Oil Sony Grease


Removal:

- (1) Remove the Capstan Motor referring to Section 3-3.
- (2) Remove the Drum Assembly referring to Section 3-14.
- (3) Remove the Switch Lever Assembly and Pinch Sub Arm Assembly referring to Section 3-16.
- (4) Remove the Timing Belt (L), RC Gear Assembly and Loading Lever Assembly referring to Section 3-17.
- (5) Remove the Coaster (Right) Assembly and Drive Gear (Right) Assembly referring to 3-20.
- (6) Remove two fixing screws and remove Reinforcement Plate SS Assembly.
- (7) Remove a fixing screw. Remove Coaster Leaf Spring and Coaster (Left) Assembly.
- (8) Remove stopper washer 1.5 and remove Drive Gear (Left) Assembly.

- Smear a grease to the mechanical chassis as shown in fig. A.
- (2) Apply a half drop of oil to the shaft. (Fig. E)
- (3) Smear a grease to the pin, shaft and projection of the Coaster (Left) Assembly. (Fig. B)
- (4) Install the pin and shaft of the Coaster (Left) Assembly to the longitudinal hole of the mechanical chassis.
- (5) Put the Drive Gear (Left) Assembly into the shaft and put the A portion into longitudinal hole. Install the gear portion so that the gear portion is engaged with Wheel Gear and UL Gear.

- (6) Put the hole of the Drive Gear (Left) Assembly to the pin of the Coaster (Left) Assembly.
- (7) Fasten the stopper washer 1.5.
- (8) Put the Coaster Leaf Spring to the shaft and pin of the Coaster (Laft) Assembly and install it with fixing screw. At this time, the tightening torque of the fixing screw is about 0.05 N·m {500gf·cm}. If tightened too much, the Coaster (Left) Assembly and Coaster Leaf Spring will be damaged.
- (9) Put the Reinforcement Plate SS Assembly to the projection of chassis and tighten the two fixing screws in order.
- (10) Smear a grease as shown in figures C and D.
- (11) Install the Coaster (Right) Assembly and Drive Gear (Right) Assembly referring to Section 3-20.
- (12) Install the Timing Belt (L), RC Gear Assembly and Loading Lever Assembly referring to Section 3-17.
- (13) Install the Switch Lever Assembly and Pinch Sub Arm Assembly referring to Section 3-16.
- (14) After putting the unit into the ULD mode, install the Drum Assembly referring to Section 3-14.
- (15) Install the Capstan Motor referring to Section 3-3.

Note: After replacement, perform the Tape Path Adjustment referring to Section 5.




3-22. REPLACEMENT OF LOADING MOTOR, BRAKE RELEASE ARM, WHEEL GEAR AND WORM ASSEMBLY

Tool: Mode Selector Sony Oil Sony Grease

Removal:

- (1) Remove the Capstan Motor referring to Section 3-3
- (2) Remove the Switch Lever Assembly and Pinch Sub Arm Assembly referring to Section 3-16.
- (3) Remove the Timing Belt (L), RC Gear Assembly and Loading Lever Assembly referring to Section 3-17.
- (4) Remove the Drive Gear (Right) Assembly referring to Section 3-20.
- (5) Remove the Drive Gear (Left) Assembly referring to Section 3-21.
- (6) Remove two fixing screws and remove Loading Motor Assembly.
- (7) Remove Brake Release Arm.
- (8) Remove stopper washer and remove Wheel Gear.
- (9) Remove Worm Assembly from six claws.

- (1) Install the Worm Assembly to the six claws.
- (2) Smear a grease to the five shaded portions of the Worm Assembly. (Fig. A)
- (3) Apply a half drop of oil to the shaft. (Fig. B)
- (4) Put the Wheel Gear to the shaft. Engage it with the gear of the Worm Assembly.
- (5) Install the Brake Release Arm.
- (6) Smear a grease to the whole gear portion of the Loading Motor Assembly.
- (7) Install the Loading Motor Assembly to the mechanical chassis with the two fixing screws.
- (8) Install the Drive Gear (Left) Assembly referring to Section 3-21.
- (9) Install the Drive Gear (Right) Assembly referring to Section 3-20.
- (10) Install the Timing Belt (L), RC Gear Assembly and Loading Lever Assembly referring to Section 3-17.
- (11) Install the Switch Lever Assembly and Pinch Sub Arm Assembly referring to Section 3-16.
- (12) After putting the unit into the ULD mode, install the Capstan Motor referring to Section 3-3.






SECTION 4 TORQUE AND BACK TENSION ADJUSTMENT

4-1. FWD BACK TENSION ADJUSTMENT

- (1) Insert a torque cassette to the unit.
- (2) Put the unit into the PLAY mode. Check that the torque reading of S Reel Table meets required specification.

Spec. 0.9×10^{-3} to 1.3×10^{-3} N·m {9 to 13 gf·cm}

(3) If the torque reading do not meet the required specification, adjust the Adjust Arm.



4-2. CHECK OF REEL TORQUE

- Setting of REV mode
 Press PLAY button and then, press REW button continuously.
- (1) Insert a torque cassette to the unit.
- (2) Put the unit into the PLAY mode and check that the torque reading of T Reel Table meets required specification.

Spec. 0.7×10^{-8} to 1.5×10^{-8} N·m {7 to 15 gf·cm}

(3) Put the unit into the REV mode and check that the torque reading of the S Reel Table meets required specification.

Spec. 2.3×10^{-3} to 3.5×10^{-3} N·m {23 to 35 gf·cm}

(4) Put the unit into the REV mode and check that the torque reading of the T Reel Table meets required specification.

Spec. 1.3×10^{-3} to 2.5×10^{-3} N·m {13 to 25 gf·cm}

(5) If the readings do not meet the required specifications, replace each Reel Table.


SECTION 5 TAPE PATH ADJUSTMENT

Alignment Information


[Track Shift]

8mm Video System employs a high precision tracking ATF (Automatic Track Finding) System which instantaneously controls tape running speed with four kinds of pilot signals. In this way, Tracking Adjustment Knob is unnecessary and it is possible to trace with accuracy. On the other hand, the adjustment of Tape Path System was difficult in the ATF System. It was impossible to adjust perfectly because the ATF System is automatically corrected even when it small miss-tracking occurs. When perform Tracking Fine Adjustment, put into the Track Shift mode. The Track Shift mode can forcibly operate the ATF System and can shift the constant tracking amount about one-fifth. Therefore, the Tracking Fine Adjustment can perform easily. Track Shift Tool is not required.


Setting Procedures of Track Shift Mode



- 1. Turn on the [SELF DIAG] switch on the operation panel of the Side Panel.
- 2. Set the [R-RUN/SET/F-RUN] switch to [SET] position.
- 3. Select the menu [105] with the [SHIFT] or [ADVANCE] button.



- 4. Set the [R-RUN/SET/F-RUN] switch to [R-RUN] position.
- 5. Select the data [11] by pressing the [SHIFT] button once.



6. Press the [RESET] button to set data.


After the TRACKING FINE ADJUSTMENT is completed, be sure to reset the mode as follows.

- 1. Turn off the [SELF DIAG] switch.
- 2. Turn off the power momentarily.

[Tape Guide Adjustment]

There are four Adjustment Guides as TG-2, 3, 6, and 7 Guides. If you want to adjust each guide, turn the Adjustment Screw as follows.

Guide Adjustment Screw		Guide Adjustment
TG-2, 3, 6	Counter- clockwise	UP
	Clockwise	Down
TG-7	Counter- clockwise	Down
	Clockwise	Up




5-1. PREPARATION FOR ADJUSTMENT

Tool: Osilloscope
Alignment tape for tracking
(WR5-1NP)

Adjustment procedure:

- (1) Clean tape path surfaces as Tape Guides, Drum, Capstan Shaft and Pinch Roller.
- (2) Connect the oscilloscope as follows. CH-1: CN24 pin 1/MB-384 Board CH-2: CN24 pin 3/MB-384 Board TRIG: CH-2
- (3) Play back the alignment tape.
- (4) Check that the RF waveform of both entrance and exit sides are flat. (Fig. A)
- (5) Set the Track Shift mode.
- (6) Check that the form and fluctuation of the RF waveform meet the specification 1. (Fig. B)
- (7) If do not meet the specifications at step (4) and (6), adjust as follows.



5-3


5-2. TRACKING ADJUSTMENT

Tool: Osilloscope
Alignment tape for tracking
(WR5-1NP)

Adjustment procedure:

- (1) Pull out the Mechanical Deck Block.
- (2) Play back the alignment tape.
- (3) Put a precision screwdriver into hole A and loosen locking screw A a little. Turn No. 3 Guide (TG-6) and flatten the waveform of entrance side.
- (4) Put a precision screwdriver into hole B and loosen locking screw B a little. Turn No. 6 Guide (TG-6) and flatten the waveform of exit side.

Note: Be careful not to turn the locking screws so much or the guides will move easily.




5-3. TRACKING FINE ADJUSTMENT

Tool: Oscilloscope Alignment tape for tracking (WR5-1NP) Cassette tape (E6-120ME)

Adjustment procedure:


- (1) Set the Track Shift mode.
- (2) Play back the alignment tape.
- (3) Perform Tape Entrance Side Adjustment.
 - (i) Turn the No. 3 Guide so that the form and fluctuation of the RF waveform meet specification 1. (Fig. A)
 - (ii) Tighten locking screw A. Check that the waveform of entrance side does not change.



- (4) Perform Tape Exit Side Adjustment.
 - (i) Turn the No. 6 Guide so that the form and fluctuation of the RF waveform meet specification 1. (Fig. A)

When the RF waveform of exit side is flat.

- (ii) Turn the No. 6 Guide clockwise a little and adjust the waveform as shown in fig. B.
- (iii) Tighten locking screw B. Check that the waveform of exit side does not change.
- (5) Perform Waveform Check of the Selfrecording and Play Back.
 - (i) Eject the alignment tape.
 - (ii) Perform the recording with no signal to the cassette tape which part is between tape top and tape middle.
 - (iii) Check that the form and fluctuation of the RF waveform meet specification 2. (Fig. C) If do not meet the specification, perform steps (2) to (4) again.
- (6) After adjustment, perform Section 5-7. Check After Adjustment.




5-4. No. 2 GUIDE ADJUSTMENT

When turning or replacing No. 2 Guide, adjust after performing No. 2 Guide (TG-2) Height Preset.

5-4-1. No. 2 Guide (TG-2) Height Preset

(1) Turn TG-2 Upper Flange and adjust the height of the TG-2 as shown in the figure.



5-4-2, No. 2 Guide (TG-2) Adjustment

Tool: Oscilloscope

Alignment tape for tracking

(WR5-1NP)

Cassette tape (E6-120ME)

Small adjustment mirror

Note: Setting of REV mode and CUE mode are as follows.

.

REV mode: While pressing PLAY button, press REW button. If removing a hand from

the REW button, the unit returns to


the PLAY mode.

CUE mode: While pressing PLAY button, press F FWD button. If removing a hand from the F FWD button, the unit returns

back to the PLAY mode.


Adjustment procedure:

- Play back a cassette tape and put into the REV mode.
- (2) Check that the tape does not curl at the lower flange of the No. 2 Guide. (Fig. A) If the tape curls, turn the upper flange of the No. 2 Guide clockwise with a screwdriver and lower the guide until the tape curl disappears.
- (3) Play back the alignment tape.
- (4) Perform the Tracking Adjustment and Tracking Fine Adjustment referring to Section 5-2 and 5-3.
- (5) Put into the Track Shift mode and play back after the CUE/REV mode. Check that the RF waveform recovers flatly within two seconds.
- (6) If the RF waveform does not recovers flatly (Fig. B), turn the upper flange of the No. 2 Guide (TG-2) counterclockwise at 90 degrees. Perform step (5) again.
- (7) Repeat steps (5) and (6) until the correct waveform can be obtain. At this time, check that the tracking waveform has not changed.
- (8) If the tracking waveform has changed, perform the Entrance Side Tracking Fine Adjustment and perform step (5) again.



5-5. No. 7 GUIDE (TG-7) ADJUSTMENT


• The No. 7 Guide (TG-7) Height Adjustment Screw is away from the No. 7 (TG-7) Guide. Refer to Alignment Information. Therefore, modify a cassette tape (E6-120ME) as shown in the figure and it is possible to adjust the No. 7 Guide in the PLAY mode.



Tool: Modified cassette tape (E6-120ME) Small adjustment mirror

Adjustment procedure:

- Play back the modified cassette tape which has been backed twenty minutes from tape end and put into the REV mode.
- (2) Check that the tape deflection between the No. 6 Guide (TG-6) and Capstan Shaft is less than 0.5 mm. If it is more than 0.5 mm, turn and adjust the No. 7 Guide (TG-7) Height Adjustment Screw.
- (3) Play back the modified cassette tape again and check that the tape deflection between the No. 7 Guide (TG-7) and Capstan Shaft is less than 0.5 mm. If it is more than the 0.5 mm, turn and adjust the No. 7 Guide (TG-7) Height Adjustment Screw. When putting into the REV mode, check that the tape deflection between the No. 6 Guide (TG-6) and Capstan Shaft is less than 0.5 mm.



5-6. CHECK OF CUE AND REV WAVEFORMS

Tool: Oscilloscope
Alignment tape for tracking
(WR5-1NP)

Adjustment procedure:


- (1) Play back the alignment tape and put into the REV mode. In this time, check that the pitches of the waveform are uniform more than five seconds as shown in the figure. If not, perform Section 5-3. Tracking Fine Adjustment and Section 5-5. No.7 Guide (TG-7) Adjustment.
- (2) Put into the CUE mode. In this time, check that the pitches of the waveform are uniform more than five seconds as shown in the figure. If not, perform Section 5-3. Tracking Fine Adjustment.





Tool: Oscilloscope
Alignment tape for tracking
(WR5-1NP)

5-7-1. Tracking Check

- (1) When putting into the Track Shift mode, check that the amplitude of the RF waveform is about four fifth as shown in the figure.
- (2) In this time, check that amplitude minimum value (E min) is more than 70% of maximum value (E max) as shown in the figure.
- (3) Check that the fluctuation of the RF waveform is as shown in the figure.








5-7-2. Recovery Check of Waveform

Tool: Oscilloscope

Alignment tape for tracking (WR5-1NP) Small adjustment mirror

- (1) Play back the alignment tape.
- (2) Put the Track Shift mode to OFF.
- (3) Put into the EJECT mode and perform threading again.
- (4) Put into the PLAY mode and check that the RF waveform recovers flatly within 2.5 seconds. Then check that there is no tape deflection around the Pinch Roller.
- (5) Play back the alignment tape after putting into the CUE/REV or FF/REW mode. Check that the RF waveform recovers flatly within 2.5 seconds. Then check that there is no tape deflection around the Pinch Roller.
- (6) Repeat steps (3) to (5).




5-7-3. Tape Running Check

Tool: Cassette tape (E6-120ME) Small adjustment mirror

(1) When playing back a cassette tape, check that the tape runs without space between tape and guide flange and tape curling (more than 0.3 mm) do not exist at five positions.

Lower flange of No. 2 Guide Upper flange of No. 3 Guide Upper flange of No. 6 Guide Lower and upper flanges of No. 7

(2) When putting into the CUE mode or REV mode, check that the tape runs without space between tape and guide flange and tape curling (more than 0.3 mm) do not exist at each flange of the guide.



5-8. SWITCHING POSITION ADJUSTMENT

Tool: Oscilloscope

Alignment tape for switching position adjustment (WR2-3NS)

Adjustment procedure:

(1) Connect the oscilloscope as follows.

CH-1: CN24 pin-1/MB-384 Board


CH-2: CN24 pin-3/MB-384 Board

Trigger: CH-2

- (2) Connect TP502 on the FP-40 to ground with a shorting clip.
- (3) Turn on the [SELF DIAG] switch on the operation panel of the Side Panel.
- (4) Set the [R-RUN/SET/F-RUN] switch to [SET] position and select the menu [101] by pressing the [SHIFT] button once.
- (5) Play back the alignment tape.
- (6) Adjust switching position with [R-RUN/SET/F-RUN] switch to meet specification A. Set the switch to [F-RUN] position for coarse adjustment.

Set the switch to $\lceil R\text{-RUN} \rfloor$ position for fine adjustment. Variable minimum unit is 1 μ sec with the switch set to $\lceil R\text{-RUN} \rfloor$ position.

- (7) Check that it meets specification B within specification A.
- (8) After adjustment, press the [COUNTER RE-SET] button, and turn off the [SELF DIAG] switch on the Side Panel, and lastly disconnect a shorting clip.





SECTION 6 CAMERA ALIGNMENT

6-1. Preparation


6-1-1. EQUIPMENT REQUIRED

- Digital voltmeter
- · Oscilloscope (100 MHz or more)
- Vectorscope
- · Waveform monitor
- · B/W monitor (Sony PVM-91/122 or equivalent)
- Color monitor (Sony PVM-1320 or equivalent)
- AC adaptor (Sony CMA-8/8A)
- · Frequency counter





6-1



6-1-3. SWITCH SETTING BEFORE ADJUSTMENT

Switch Setting of the camera side panel

GAIN switch : OdB
OUTPUT switch : CAM

WHITE BAL switch: PRESET

FILTER knob : 1

SHUTTER switch: OFF

IRIS(Lens): Manual ZOOM(Lens): Manual

IE-33 Board

S1(CB 75%/100%): 75%

ES-4 Board

S1(VTR↔TEST): VTR (Upper side)

AT-70 Board

S1(FRM/FLD): FLD

S2(FULL FUNC/OPE): OPE

S3(OPE/KNEE HI): OPE

S4(ADJ/OPE): ADJ

Note: After the adjustment, return the S4(ADJ/OPE)/AT-70 board to "OPE" position.

6-1-4. Note on adjustment

Note

(1) As the following adjusting control has no turning stopper, take care not to over-turn it.



Potentiometer Mechanical center condition

- (2) Before adjustment, be sure to allow for 10-minute warmup time.
- (3) If the amplitude level of the measured waveform is blurred on the waveform monitor screen, set the RESPONSE switch on the waveform monitor to "LUM" mode.

6-1-5. ADJUSTMENT ITEM

6-2. CCD DRIVE SYSTEM ADJUSTMENT

6-2-1. G/R/B V SUBSTRATE VOLTAGE ADJUSTMENT

6-2-2. G/R/B RG VOLTAGE ADJUSTMENT

6-3. SYNC SIGNAL SYSTEM ADJUSTMENT

6-3-1. SUB-CARRIER FREQUENCY ADJUSTMENT

6-4. ENCODER SYSTEM ADJUSTMENT

6-4-1. COLOR-BAR 75%/100% ADJUSTMENT

6-4-2. CARRIER BALANCE ADJUSTMENT

6-4-3. COLOR-BAR SIZE ADJUSTMNT

6-4-4. INT CB Y ADJUSTMENT

6-4-5. COLOR VECTOR ADJUSTMNT

6-4-6. MATRIX ADJUSTMENT

6-5. VIDEO PROCESS SYSTEM ADJUSTMENT

6-5-1. 1H OUT BALANCE ADJUSTMENT

6-5-2. 2H OUT BALANCE ADJUSTMENT

6-5-3. 1H GAIN ADJUSTMENT

6-5-4. 2H GAIN ADJUSTMENT

6-5-5. G-ch/B-ch/R-ch INPUT GAIN ADJUSTMENT

6-5-6. G-ch GAIN/GAMMA/PED ADJUSTMENT

6-5-7. R-ch/B-ch GAIN/PED ADJUSTMENT

6-5-8. G-ch BLACK SET AND PEDESTAL ADJUSTMENT

6-5-9. R-ch/B-ch BLACK SET AND PEDESTAL ADJUSTMNT

6-5-10. KNEE ADJUSTMENT

6-5-11. PRE KNEE ADJUSTMENT

6-5-12. PR WHITE CLIP ADJUSTMENT

6-5-13. ALIASING ADJUSTMENT

6-5-14. APERTURE CRISPENING ADJUSTMENT

6-5-15. YH LEVEL ADJUSTMENT

6-5-16. DTL CRISPENING ADJUSTMENT

6-5-17. DTL ALIASING ADJUSTMENT

6-5-18. H/V RATIO ADJUSTMENT

6-5-19. DETAIL LEVEL ADJUSTMNT

6-5-20. ES WHITE CLIP ADJUSTMENT

6-5-21. ZEBRA LEVEL ADJUSTMNT

6-5-22. AUTO IRIS ADJUSTMENT

6-2. CCD DRIVE SYSTEM ADJUSTMENT

6-2-1, G/R/B V SUBSTRATE VOLTAGE ADJUSTMENT

Note: Perform this adjustment only when replacing the adjusting control on the MB-384 board or replacing the mounted circuit board "MB-384" or replacing the front unit Assy. When the adjusting control on the MB-384 board was turned by accident, this adjustment is required.

Equipment: Digital voltmeter

Adjustment Procedure

 Perform adjustment in order of G-ch, R-ch and B-ch as shown below.

MB-384 Board

	Test point (GND: E1)	Adjusting point
G-ch	TP4	⊘ RV4
R-ch	TP5	⊘ RV5
B-ch	TP6	⊘ RV6

Adjust to the V SUB voltage (± 0.2 V) shown on the label sticking to the front unit Assy.

(Exampl	e)
---------	----

	Vsub	RG	
R	13.5	2.0	
G	13.5	2.0	
В	12.5	2.0	
	1	1	
	Vdc	Vdc	

6-2-2. G/R/B RG VOLTAGE ADJUSTMENT

Note: Perform this adjustment only when replacing the adjusting control on the MB-384 board or replacing the mounted circuit board "MB-384" or replacing the front unit assy. When the adjusting control on the MB-384 board was turned by accident, this adjustment is required.


Equipment: Oscilloscope Adjustment Procedure

 Perform adjustment in order of G-ch, R-ch and B-ch as shown below.

MB-384 Board

	Test point (GND: E1)	Adjusting point
G-ch	TP1	⊘ RV1
R-ch	TP3	O RV3
B-ch	TP2	⊘ RV2

Adjust to the RG voltage (± 0.2 V) shown on the label sticking to the front unit Assy.



6-3. SYNC SIGNAL SYSTEM ADJUSTMENT

6-3-1. SUB-CARRIER FREQUENCY ADJUSTMENT

Equipment: Frequency counter To be extended: ES-4 Board

Test point: TP5(GND: E1)/ES-4 Board Adjusting point: **②**RV15/ES-4 Board Specification: 3,579,545±10 Hz

6-4. ENCODER SYSTEM ADJUSTMENT


6-4-1. COLOR-BAR 75%/100% ADJUSTMENT

Equipment: Oscilloscope
To be extended: IE-33 Board


Preparation: OUTPUT switch/camera side panel→BARS

Adjustment Procedure

1.S1(75%/100%)/IE-33 Board→75% 2.Test point: pin A19/extension board Adjusting point: **②**RV16/IE-33 Board Specification: A=0.75±0.01 V




3.S1(75%/100%)/IE-33 Board→100% 4.Test point: pin A19/extension board Adjusting point: ②RV17/IE-33 Board Specification: B=1.00±0.01 V




5.After the adjustment, return S1/IE-33 board to 75%.

ES-4/4P BOARD



IE-33/33P BOARD



6-4-2. CARRIER BALANCE ADJUSTMENT

Equipment: Vectorscope (MAX GAIN)


To be extended: ES-4 Board

Preparation: OUTPUT switch/camera side panel→BARS

Adjustment Procedure

Adjust @RV12 and @RV13/ES-4 board so that the black beam spot is positioned in the center of the vectorscope

screen




6-4-3. COLOR-BAR SIZE ADJUSTMENT

Equipment: Oscilloscope
To be extended: IE-33 Board


Preparation: OUTPUT switch/camera side panel→BARS

Adjusting point: ORV14/IE-33 Board


Specification: $A=4.0\pm0.2 \mu s$







IE-33/33P BOARD




6-4-4. INT CB Y ADJUSTMENT

Equipment: Waveform monitor To be extended: ES-4 Board

Preparation: OUTPUT switch/camera side panel→BARS

Adjustment Procedure

1.Adjusting point: ♠RV4/ES-4 Board Specification: A=7.5±0.5 IRE 2.Adjusting point: ♠RV3/ES-4 Board Specification: B=77±2 IRE 3.Adjusting point: ♠RV5/ES-4 Board Specification: C=40±2 IRE



6-4-5. COLOR VECTOR ADJUSTMENT


Equipment: Vectorscope
To be extended: ES-4 Board


Preparation:

- · GAIN switch/Vectorscope→75% CAL
- Adjust the PHASE control on the vectorscope so that the burst spot is overlapped to the 75% axis.
- · OUTPUT switch/camera side panel→BARS


Adjustment Procedure

- 1.Adjust **@**RV8/ES-4 board so that the burst spot is located at 75% scale mark on the vectorscope screen.
- 2. Adjust the following controls alternately so that each beam spot stays inside the reference frame "\'\'\'\'\''.
 - OLV1/ES-4 board
 - ORV9/ES-4 board
 - ORV10/ES-4 board
 - ●RV14/ES-4 board
- 3.Repeat procedures 1 through 2 several times.





ES-4/4P BOARD




6-4-6. MATRIX ADJUSTMENT


Equipment: Waveform monitor To be extended: PR-159 Board

Preparation: OUTPUT switch/camera side panel→BARS

Adjustment Procedure

 Adjust ORV1 and ORV2/PR-159 board alternately so that the carrier leakage "A" is minimum.





TP2

PR-159/159P BOARD

6-5. VIDEO PROCESS SYSTEM ADJUSTMENT

6-5-1. 1H OUT BALANCE ADJUSTMENT

Note: Perform the adjustment only when replacing the delay


line (IC14 or IC15).

Object: Burst chart


Equipment: Oscilloscope, Waveform monitor

To be extended: IE-33 Board Adjustment Procedure

1. Make sure that the lens is best focused. And adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.




2.Adjust the lens iris so that the VIDEO OUT level is 100 ± 2 IRE.



3.Test point: TP8(GND: E1)/IE-33 board.

To get the following picture, set the LINE SEL switch on the waveform monitor to "15 LINES". And select the center of the monitor screen by using the VAR control of LINE SEL. Adjusting point: • RV7/IE-33 board

Specification: Make sure that a double waveform does not appear.



RV3 TP5 RV2 TP3 RV1 TP1 RV3 TP5 RV2 TP3 RV1 TP1 BACK TP6 GLEVEL TP6 GLEVEL TP6 GLEVEL TP6 GLEVEL TP6 GLEVEL TP6 GLEVEL TP7 GLEVEL TP6 GLEVEL TP7 GLEVEL TP7 GLEVEL TP7 GLEVEL TP6 GLEVEL TP7 GLEVEL

IE-33/33P BOARD

6-5-2. 2H OUT BALANCE ADJUSTMENT


Note: Perform the adjustment only when replacing the delay

line (IC16 or IC17). Object: Burst chart


Equipment: Oscilloscope, Waveform monitor

To be extended: IE-33 Board Adjustment Procedure

1. Make sure that the lens is best focused. And adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.



2.Adjust the lens iris so that the VIDEO OUT level is 100 ± 2 IRE.





3.Test point: TP9(GND: E1)/IE-33 board.

To get the following picture, set the LINE SEL switch on the waveform monitor to "15 LINES". And select the center of the monitor screen by using the VAR control of LINE SEL

Adjusting point: ORV9/IE-33 board

Specification: Make sure that a double waveform does not appear.





6-5-3, 1H GAIN ADJUSTMENT

Object: Grayscale chart

Equipment: Oscilloscope, Waveform monitor


To be extended: IE-33 Board

Preparation:

WHITE BAL switch/camera side panel→PRESET


Adjustment Procedure

1. Adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.




(monitor screen).


2.Adjust the lens iris so that the video level at VIDEO OUT is 100 ± 2 IRE.



- 3.Put the oscilloscope into GAIN ADD mode and into CH-2 INVERT mode.
- 4. Connect CH-1 and CH-2 of oscilloscope to TP7 (GND: E1) on the IE-33 board. Adjust CH1-VAR or CH2-VAR control on the oscilloscope so that the waveform becomes flat for gain correction.
- 5.Connect CH-1 of oscilloscope to TP7 and CH-2 to TP8 on the IE-33 board.

6.Adjust ORV8/IE-33 board so that the waveform becomes flat.





6-5-4. 2H GAIN ADJUSTMENT

Object: Grayscale chart

Equipment: Oscilloscope, Waveform monitor


To be extended: IE-33 Board

Preparation:

WHITE BAL switch/camera side panel→PRESET


Adjustment Procedure

1.Adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.




(monitor screen)


2.Adjust the lens iris so that the video level at the VIDEO OUT is 100 ± 2 IRE.




- 3.Put the oscilloscope into GAIN ADD mode and into CH-2 INVERT mode.
- 4.Connect CH-1 and CH-2 of oscilloscope to TP7 (GND: E1) on the IE-33 board. Adjust CH1-VAR or CH2-VAR control on the oscilloscope so that the waveform becomes flat for gain correction.
- 5.Connect CH-1 of oscilloscope to TP7 and CH-2 to TP9 on the IE-33 board.

6.Adjust • RV10/IE-33 board so that the waveform becomes flat.







6-5-5. G-ch/B-ch/R-ch INPUT GAIN ADJUSTMENT

Note: Use a reflection type white chart for G-ch/B-ch/R-ch INPUT GAIN ADJUSTMENT. Control the light so that the white area of chart is exactly 3200K of color temperature. If the pattern box is used, PTB-500 should be used.

Object: Grayscale chart Equipment: Oscilloscope To be extended: IE-33 Board


Preparation:

WHITE BAL switch/camera side panel→PRESET

OUTPUT switch/camera side panel→CAM

Adjustment Procedure


1.Adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.



(monitor screen)

2.Test point: TP3(GND: E1)/IE-33 Board


Adjusting point: Lens iris Specification: A=260±5 mV




3.Perform adjustment in order of G-ch, R-ch and B-ch as shown below.

IE-33 Board

	Test point (GND: E1)	Adjusting point	Specification
G-ch	TP4	⊘ RV2	
R-ch	TP2	⊘ RV1	B=115±5mV
B-ch	ТР6	O RV3	



IE-33/33P BOARD



6-5-6, G-ch GAIN/GAMMA/PED ADJUSTMENT

Note: • The item 6-5-5. G-ch/B-ch/R-ch INPUT GAIN ADJUSTMENT must be complete before beginning this adjustment.

 When this adjustment is done, perform Section 6-5-7. R-ch/B-ch GAIN/PED ADJUSTMENT through Section 6-5-12. PR WHITE CLIP ADJUSTMENT continuously.

Object: Grayscale chart Equipment: Oscilloscope To be extended: PR-159 Board

Preparation:

◆RV7/PR-159 board→fully counterclockwise

• RV8/PR-159 board→fully clockwise
• Output

ORV9/PR-159 board→fully counterclockwise ○

ORV10/PR-159 board→fully counterclockwise ○


ORV11/PR-159 board→fully counterclockwise ○

Trigger: pin A10/extension board

Preparation: GAIN switch/camera side panel→0dB


Adjustment Procedure

1. Adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.



(monitor screen)

2.Adjust the lens iris so that the video level at pin A26(GND: pin B1)/extension board is 115 ± 5 mV.



3. Put the cap on the lens.


 Test point: pin B21(GND: pin B1)/extension board Adjusting point: ORV13/PR-159 Board

Specification: A=25±2 mV




5. Remove the cap from the lens.

6.Test point: pin B21(GND: pin B1)/extension board Specification: B=550±20 mV; ◆RV6/PR-159 Board C=1000±10 mV; ◆RV16/PR-159 Board



7. Repeat procedures 3 through 6 several times.

Note: After the adjustment, carry out Section 6-5-7. R-ch/ B-ch GAIN/PED ADJUSTMENT.



6-5-7, R-ch/B-ch GAIN/PED ADJUSTMENT

Note: The item 6-5-6. G-ch GAIN/GAMMA/PED ADJUST-MENT must be complete before beginning this adjustment.

Object: Grayscale chart

Equipment: Waveform monitor To be extended: PR-159 Board

Preparation:

ORV7/PR-159 board→fully counterclockwise ○

◆RV8/PR-159 board→fully clockwise


◆RV9/PR-159 board→fully counterclockwise

◆RV10/PR-159 board→fully counterclockwise

• RV11/PR-159 board→fully counterclockwise


Test point: VIDEO OUT Adjustment Procedure

1. Adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.




(monitor screen)

2. Adjust the lens iris so that the video level at pin A26(GND: pin B1)/extension board is 115±5 mV.



- 3. Put the cap on the lens.
- 4.Adjusting point: **②**RV12, **②**RV14/PR-159 Board Specification: A=Minimum




5. Remove the cap from the lens.

6.To get the following picture, set the LINE SEL switch on the waveform monitor to "15 LINES". And select the center of the monitor screen by using the VAR control of LINE SEL.

7. Adjusting point: ORV15, ORV17/PR-159 Board

Specification: B=Minimum


(WFM: BPF 3.58 mode).



8. Repeat Procedures 3 through 7 several times.

Note: After the adjustment, carry out Section 6-5-8. G-ch BLACK SET AND PEDESTAL ADJUSTMENT.

PR-159/159P BOARD



6-5-8. G-ch BLACK SET AND PEDESTAL ADJUSTMENT

Note: Section 6-5-7. R-ch/B-ch GAIN/PED ADJUSTMENT must be complete before beginning this adjustment.

Make sure that 18dB gains is set with the GAIN switch (camera side panel) set to HIGH position.

Lens iris: Close''C"
Equipment: Oscilloscope
To be extended: PR-159 Board

Preparation:

ORV7/PR-159 board→fully counterclockwise ○

◆
RV8/PR-159 board→fully clockwise

◆
RV8/PR-159 board→fully clockwise

◆
RV8/PR-159 board→fully clockwise

**The control of the control

◆RV9/PR-159 board→fully counterclockwise ○

ORV10/PR-159 board→fully counterclockwise ○

◆RV11/PR-159 board—fully counterclockwise ○

Trigger: pin A10/extension board

Adjustment Procedure

1.Adjust ◆RV5/IE-33 board so that the pedestal level does not change when the GAIN switch on the side of the camera is switched over from 0 dB to HIGH(18dB).



2.GAIN switch/camera side panel→0dB


3.Test point: B21(GND: pin B1)/extension board Adjusting point: • RV13/PR-159 Board

Specification: C = 25±2 mV



Note: After the adjustment, carry out Section 6-5-9. R-ch/ B-ch BLACK SET AND PEDESTAL ADJUSTMENT.

PR-159/159P BOARD



6-5-9. R-ch/B-ch BLACK SET AND PEDESTAL ADJUSTMENT

Note: • Section 6-5-8. G-ch BLACK SET AND PEDESTAL ADJUSTMENT must be complete before beginning this adjustment.

 Make sure that 18dB gains is set with the GAIN switch (camera side panel) set to HIGH position.


· Set the GAIN switch/vectorscope to MAX.

Lens iris: Close"C"
Equipment: Vectorscope
To be extended: PR-159 Board

Test point: VIDEO OUT Adjustment Procedure


1.GAIN switch/camera side panel→HIGH(18dB)

2.Adjust ORV4 and ORV6/IE-33 board so that the black beam spot is positioned in the center of the vectorscope.



3.GAIN switch/camera side panel→0dB

4.Adjust •RV12 and •RV14/PR-159 board so that the black beam spot is positioned in the center of the vectorscope.



5. Repeat procedures 1 through 4 several times.

Note: After the adjustment, carry out Section 6-5-10. KNEE ADJUSTMENT.

6-5-10. KNEE ADJUSTMENT


Note: Section 6-5-9 R-ch/B-ch BLACK SET AND PEDESTAL ADJUSTMENT must be complete before beginning this

adjustment.

Object: Grayscale chart Equipment: Oscilloscope To be extended: PR-159 Board Test point: pin B21/extension board

Adjustment Procedure


 Adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.




(monitor scrren)

2.Adjusting point: Lens iris

Specification: $A=1020 \pm 0.00$ mV




3.Adjusting point: **⊘** RV7/PR-159 Board Specification: B=1000 ± 00 mV



Note: After the adjustment, carry out Section 6-5-11. PRE KNEE ADJUSTMENT.

PR-159/159P BOARD



6-5-11. PRE KNEE ADJUSTMENT

Note: Section 6-5-10 KNEE ADJUSTMENT must be complete

before beginning this adjustment.


Object: Grayscale chart

Equipment: Oscilloscope, Waveform monitor

To be extended: PR-159 Board Trigger: pin A10/extension board

Adjustment Procedure


1. Adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.



(monitor screen)

2.Test point: pin A26(GND: pin B1)/extension board


Adjusting point: Lens iris Specification: A=350±10 mV



3.Test point: pin B21(GND: pin B1)/extension board


Adjusting point: ORV10/PR-159 Board

Specification: B=1150 ±20 mV



4.Test point: VIDEO OUT

Adjusting point: **②**RV9, **②**RV11/PR-159 Board Specification: Carrier leakages C, D, E→Minimum



Note: After the adjustment, carry out Section 6-5-12 PR WHITE CLIP ADJUSTMENT.

6-5-12. PR WHITE CLIP ADJUSTMENT

Note: Section 6-5-11 PRE KNEE ADJUSTMENT must be

complete before beginning this adjustment.

Make sure that 18dB gains is set with the GAIN switch

(camera side panel) set to 18dB.

Object: Grayscale chart Equipment: Oscilloscope To be extended: PR-159 Board


Preparation: GAIN switch/camera side panel→0dB

Test point: pin B21/extension board

Adjustment Procedure

1.Adjust the zoom control of the lens so that the chart frame


touches the underscanned monitor frame.



(monitor screen)


2.GAIN switch/camera side panel→HIGH(18dB)

Adjusting point: **②**RV8/PR-159 Board Specification: A=1150±10 mV



Note: After the adjustment, set switch as follows.
GAIN switch/camera side panel→0dB

PR-159/159P BOARD



6-5-13, ALIASING ADJUSTMENT

Note: When this adjustment is done, perform Section 6-5-14
APERTURE CRISPENING ADJUSTMENT through Section 6-5-18 DETAIL LEVEL ADJUSTMENT continuously.

Object: Burst chart


Equipment: Waveform monitor

Test point: VIDEO OUT

Preparation: ●RV4/PR-159 board→fully clockwise


Adjustment Procedure

1.Make sure that the lens is best focused. And adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.



(monitor screen)


2.Adjusting point: Lens iris Specification: A=80±2 IRE




3.Adjusting point: RV13/IE-33 Board

Specification: B=Minimum

(To get the following picture, set the LINE SEL switch on the waveform monitor to "15 LINES". And select the center of the monitor screen by using the VAR control of LINE SEL.)



IE-33/33P BOARD



В

6-5-14. APERTURE CRISPENING ADJUSTMENT

Note: Section 6-5-13 ALIASING ADJUSTMENT must be complete before beginning this adjustment.

Object: Burst chart


Equipment: Waveform monitor To be extended: ES-4 board

Preparation: **②**RV4/PR-159 board→Fully clockwise **○**

Test point: VIDEO OUT Adjustment Procedure

1. Make sure that the lens is best focused. And adjust the zoom control of the lens so that the chart frame touches


the underscanned monitor frame.



2.Adjusting point: Lens iris


Specification: A=80±2 IRE (0.5MHz LEVEL)


To get the following picture, set the LINE SEL switch on the waveform monitor to "15 LINES". And select the center of the monitor screen by using the VAR control of LINE SEL.




3.Adjusting point: ORV1/ES-4 Board

Specification: B=Minimum (4.0 MHz LEVEL)





ES-4/4P BOARD



6-5-15. YH LEVEL ADJUSTMENT

Note: Section 6-5-14 APERTURE CRISPENING ADJUST-MENT must be complete before beginning this adjust-

ment.


Object: Burst chart

Equipment: Waveform monitor To be extended: ES-4 Board

Preparation: ●RV4/PR-159 board→Fully clockwise ○

Test point: VIDEO OUT Adjustment Procedure

1. Make sure that the lens is best focused. And adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.




(monitor screen)

2. Adjusting point: Lens iris

Specification: A=80±2 IRE (0.5MHz LEVEL)


(To get the following picture, set the LINE SEL switch on the waveform monitor to "15 LINES". And select the center of the monitor screen by using the VAR control of LINE SEL.)




3.Adjusting point: **②**RV2/ES-4 Board Specification: B=85±3 IRE (4.0MHz LEVEL)

Note: After the adjustment, carry out Section 6-5-16. DTL CRISPENING ADJUSTMENT.

PR-159/159P BOARD







6-5-16. DTL CRISPENING ADJUSTMENT

Note: Section 6-5-15 $Y_{\rm H}$ LEVEL ADJUSTMENT must be complete before beginning this adjustment.

Object: Burst chart


Equipment: Oscilloscope, Waveform monitor

To be extended: PR-159 Board

Preparation: **②**RV5/PR-159 board→Fully clockwise **○**


Adjustment Procedure

1.Make sure that the lens is best focused. And adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.




(monitor screen)

2.Test point: VIDEO OUT
Adjusting point: Lens iris
Specification: A=80±3 IRE



3.Test point: pin B15(GND: pin B1)/extension board


Adjusting point: **②**RV4/PR-159 Board Specification: B=250±10 mV



4.Test point: pin B15(GND: pin B1)/extension board


Adjusting point: ORV5/PR-159 Board

Specification: C=B×95%



Note: After the adjustment, carry out Section 6-5-17. DTL ALIASING ADJUSTMENT.

PR-159/159P BOARD



6-5-17. DTL ALIASING ADJUSTMENT


Note: Section 6-5-16 DTL CRISPENING ADJUSTMENT must be complete before beginning this adjustment.

Object: Burst chart

Equipment: Waveform monitor


Test point: VIDEO OUT Adjustment Procedure

1. Make sure that the lens is best focused. And adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.



(monitor screen)


2.Adjusting point: Lens iris Specification: A=80±3 IRE



3. To get the following picture, set the LINE SEL switch on the waveform monitor to "15 LINES". And select the center of the monitor screen by using the VAR control of LINE SEL.


Adjusting point: ORV11/IE-33 Board

Specification: B=Minimum



Note: After the adjustment, carry out Section 6-5-18 H/V RATIO ADJUSTMENT.





6-5-18. H/V RATIO ADJUSTMENT

Note: Section 6-5-17 DTL ALIASING ADJUSTMENT must be complete before beginning this adjustment.

Object: Grayscale chart

Equipment: B/W monitor screen

Preparation: WHITE BAL switch/camera side panel


→PRESET

Test point: VIDEO OUT

Adjusting point: ORV12/IE-33 Board


Adjustment Procedure

1. Make sure that the lens is best focused. And adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.




(monitor screen)


2.Adjusting point: Lens iris Specification: A=80±2 IRE



3. Observing the indicated point on the B/W monitor (See the figure below), adjust •RV12/IE-33 board so that the DTL H and V are balanced.



Note: After the adjustment, carry out Section 6-5-19. DETAIL ADJUSTMENT.



6-24

6-5-19. DETAIL LEVEL ADJUSTMENT

Note: Section 6-5-18 H/V RATIO ADJUSTMENT must be complete before beginning this adjustment.

Object: Grayscale chart Equipment: Waveform monitor

Preparation: WHITE BAL switch/camera side panel


→PRESET

Test point: VIDEO OUT

Adjusting point: ORV4/PR-159 Board


Adjustment Procedure

 Adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.



(monitor screen)

- 2.Adjust the lens iris so that the video level at VIDEO OUT is 80 ± 2 IRE.
- 3. Adjust ♠RV4/PR-159 board so that the detail level at both ends of the white level is 12±2 IRE. (Note: If the two DTL levels are not balanced, take the higher one.)



4.Repeat Section 6-5-18. H/V RATIO ADJUSTMENT and 6-5-19. DETAIL LEVEL ADJUSTMENT several times.

PR-159/159P BOARD RY12 REED RY12 REED RY13 RY1 RY10 RY14 RY10 RY10

6-5-20. ES WHITE CLIP ADJUSTMENT

Object: Burst chart

Equipment: Waveform monitor To be extended: ES-4 Board Test point: VIDEO OUT


Preparation:

WHITE BAL switch/camera side panel→PRESET

• GAIN switch/camera side panel→0dB

Adjustment Procedure


1. Make sure that the lens is best focused. And adjust the zoom control of the lens so that the chart frame touches the underscanned monitor frame.




(monitor screen)

2.Adjusting point: Lens iris
Specification: A=110±2 IRE
3.Adjusting point: ♠RV6/ES-4 Board

Specification: B=125⁺⁰₋₂ IRE (the highest level)



ES-4/4P BOARD



6-5-21. ZEBRA LEVEL ADJUSTMENT


Object: Grayscale chart Equipment: Viewfinder screen To be extended: ES-4 Board

Preparation: OUTPUT switch/camera side panel→ CAM

Adjusting point: ORV7/ES-4 Board


Adjustment Procedure

1. Adjust the zoom control so that the grayscale chart frame touches the understand picture frame on the monitor.




(monitor screen)

2.Adjusting point: Lens iris Specification: A=70±2 IRE



3.Adjust ORV7/ES-4 board so that the zebra pattern appears in the portion A of the VF screen as shown below.




6-5-22. AUTO IRIS ADJUSTMENT

Object: Grayscale chart Equipment: Viewfinder screen

Adjustment Procedure

1. Adjust the zoom control so that the grayscale chart frame touches the understand picture frame on the monitor.



(monitor screen)

2.IRIS AUTO/MANU (Lens)→MANU

3.POWER switch/camera side panel→OFF


4.S2 (FULL FUNC↔OPE) /AT-70 board

→FULL FUNC (Under side)

S4 (ADJ/OPE) /AT-70 board→OPE (Upper side)

5. Turn the POWER switch/camera side panel ON while pressing both UP button and DOWN button on the front panel.

6.Adjust the lens iris so that the VIDEO OUT level "A" is 100 ± 1 IRE.



7.Press the UP button on the front panel only once for memorizing the auto iris level.

Note: After the adjustment, set S2 (FULL FUNC⇔OPE) / AT-70 board to "OPE" (Upper side) position.

SECTION 7 VTR ELECTRICAL ALIGNMENT

Variable voltage power supply (+12V, 5A)

7-1. PREPARATION

7-1-1. EQUIPMENT REQUIRED

- · Oscilloscope (100 MHz or more)
- Vectorscope
- Waveform monitor
- Frequency counter
- · Audio signal generator
- · Audio level meter
- · Shorting clip
- Blank tape(P6-60MP or equivalent), (E6-60ME or equivalent)
- · Alignment tape

Name (Part No.)	REC	Tape Type	Tape Speed	Contents	
	mode			Video Area	PCM Area
Video freq. resp. WR5-7NE (8-967-995-13)	Hi8	ME	SP	RF Sweep 0 to 15MHz Marker: 2.0 MHz 4.5 MHz 7.0 MHz 8.5 MHz 10.0 MHz	
SP operation check WR5-5NSP (8-967-995-42)	STD	MP	SP	VIDEO SIGNAL Color-bar 4 min. Monoscope 4 min. AUDIO SIGNAL 400 Hz 60% mod.	AUDIO SIGNAL(PCM) Monoscope Section 20 Hz 20 sec. 400 Hz 20 sec. 14 kHz 20 sec. Color-bar Section 1 kHz 4 sec.
SP operation check WR5-8NSE (8-967-995-43)	Hi8	ME	SP		AUDIO SIGNAL(PCM) 400 Hz 20 min.


7-1-2. ADJUSTMENT FIXTURE

Adjustment Fixture for SS-50 board extension

- · SS Flexible Board 1 (Type JH-099, 26-pin),
 - (Sony part No. J-6360-990-A) 2 pieces
- SS Flexible Board 2 (Type JH-100, 14-pin),
 - (Sony part No. J-6361-000-A) 1 piece
- · SS Flexible Board 3 (Type JH-101, 13-pin),
 - (Sony part No. J-6361-010-A) 1 piece
- · SS Flexible Board 4 (Type JH-102, 11-pin),
 - (Sony part No. J-6361-020-A) 1 piece

Tracking Adjustment Fixture (Type JH-541), (Sony part No. J-6365-410-A)

7-1-3. CONNECTION



7-1-4. INITIAL SETTING AND ADJUSTMENT

Initial Setting

Setting of the camera side

Side panel

GAIN switch: 0dB

OUTPUT switch: BARS

WHITE BAL switch: PRESET

S1(75%/100%)/IE-33 Board: 100%

Setting of the VTR side

Side panel

AUDIO SELECT PCM1AUTO

PCM2 ·····AUTO

AFMAUTO

MONITOR SELECTPCM, ST/MIX

CH1/CH2 Switches CH1······LINE

CH2·····LINE

Note: Do not touch the switches as mentioned above without particular indication.

Initial Adjustment

Note: 1. Before adjustment, connect the equipments referring to Section 7-1-3 CONNECTION. Check that it meets the specifications in Section 7-1-5 COLOR BAR SIGNAL


2. Before adjustment, turn the POWER ON and allow for 10 minute warm-up time.

7-1-5. COLOR BAR SIGNAL


Equipment: Vectorscope, Waveform monitor

Preparation: OUTPUT switch/Camera side panel→BARS

Specification:



Chroma Level



Note: When it does not meet the specifications, perform Section 6-4. Encoder System Adjustment.

7-2. SERVO SYSTEM ADJUSTMENT

7-2-1. PWM OSCILLATION FREQUENCY ADJUSTMENT

Equipment: Frequency counter To be extended: SS-50 Board

Preparation:

 Play back the color-bar signal portion of the alignment tape WR5-5NSP.


Test point: Collector of the transistor Q300(GND: E1)/SS-

50 Board

Adjusting point: @RV300/SS-50 Board

Specification: 400±2 kHz

SS-50 BOARD



7-3. AUDIO SYSTEM ADJUSTMENT

7-3-1. AUDIO AGC ADJUSTMENT

Equipment: Audio level meter To be extended: FP-40 Board

Preparation:

· AUDIO IN: CH-1 400 Hz,+4 dBu

 AUDIO INPUT SELECT: PCM1 CH-1/CAM→CH-1

• AUDIO SELECT: PCM1 AUTO/MAN→AUTO

• EE mode

Test point: TP3(GND: E1)/FP-40 Board Adjusting point: ♠RV4/FP-40 Board Specification: −10.0±0.2 dBu

7-3-2. AUDIO AFM EE LEVEL ADJUSTMENT

Equipment: Audio level meter To be extended: FP-40 Board

Preparation:

• AUDIO IN: CH-1 400 Hz, +4 dBu

 AUDIO INPUT SELECT: PCM1 CH-1/CAM→CAM

AUDIO SELECT:
 AFM AUTO/MAN→AUTO

• EE mode


7-4

Test point: TP201(GND: E1)/FP-40 Board Adjusting point: ◆RV203/FP-40 Board

Specification: -10.0±0.2 dBu

FP-40 BOARD

EVW-300 (UC)



7-3-3. PCM MASTER CLOCK ADJUSTMENT

Equipment: Frequency counter
To be extended: AU-162 Board

Preparation:

Connect TP201/AU-162 and TP202/AU-162 with shorting clip.

2. Connect TP203/AU-162 and TP109/AU-162 with shorting clip.

3. EE mode

Test point: TP103(GND: E101)/AU-162 Board Adjusting point: OCV201/AU-162 Board

Specification: 11.58±0.01 MHz

Note: After the adjustment, remove a shorting clip.

7-3-6. AUDIO PCM NR DECODE LEVEL ADJUSTMENT

Equipment: Audio level meter
To be extended: AU-162 Board

Preparation:

 Play back the Audio 400Hz portion of the alignment tape WR5-5NSP.

Adjusting point: ORV3/AU-162 Board

Specification: TP1(GND: E1)/AU-162 Board;

-14.0±0.5 dBu

TP2(GND: E1)/AU-162 Board;

-14.0±0.5 dBu

Note: If there is the level difference between the TP1 and TP2, adjust the RV3 to be on the center value.

7-3-4. PCM PLAYBACK VCO FREE-FREQUENCY ADJUSTMENT

Equipment: Frequency counter To be extended: AU-162 Board

Preparation:

- Connect TP104/AU-162 and TP109/AU-162 with shorting clip.
- Connect TP105/AU-162 and TP109/AU-162 with shorting clip.
- 3. Play back the Audio 400Hz portion of the alignment tape WR5-5NSP.

Test point: TP106(GND: E101)/AU-162 Board Adjusting point: **O**RV102/AU-162 Board

Specification: 11.58±0.01 MHz

Note: After the adjustment, remove a shorting clip.

7-3-5. AUDIO PCM D/A CONVERTER LEVEL ADJUSTMENT

Equipment: Audio level meter To be extended: AU-162 Board

Preparation:

 Play back the Audio 400Hz portion of the alignment tape WR5-5NSP.

Adjusting point: • RV6/AU-162 Board Specification: TP3(GND: E1)/AU-162 Board;


-10.0±0.2 dBu

TP4(GND: E1)/AU-162 Board;

 $-10.0 \pm 0.2 \text{ dBu}$

Note: If there is the level difference between the TP3 and TP4, adjust the RV6 to be on the center value.

AU-162 BOARD



7-3-7. AUDIO PCM A/D CONVERTER OFFSET ADJUST-MENT

Equipment: Oscilloscope
To be extended: AU-162 Board

Preparation:

• AUDIO IN: 400 Hz, -∞

· AUDIO SELECT:

PCM1 AUTO/MAN→MAN PCM2 AUTO/MAN→MAN

• REC mode


 AUDIO LEVEL PCM1 control(side panel)→Fully counterclockwise ○

 AUDIO LEVEL PCM2 control(side panel)→Fully counterclockwise ∩

Test point: CH1 TP108(GND: E101)/AU-162 Board

CH2 TP107(GND: E101)/AU-162 Board

Adjusting point: • RV4/AU-162 Board • RV7/AU-162 Board



Adjust upper and lower brightnesses to be the same.

7-3-9. PCM2 EE LEVEL ADJUSTMENT

Equipment: Audio level meter To be extended: AU-162 Board

Preparation:

• AUDIO IN: CH-2 400 Hz, +4 dBu

· AUDIO SELECT:

PCM2 AUTO/MAN→AUTO

• EE mode

Test point: TP2(GND: E1)/AU-162 Board Adjusting point: **⊘** RV2/AU-162 Board

Specification: -18.0±0.2 dBu

7-3-8. PCM1 EE LEVEL ADJUSTMENT

Equipment: Audio level meter To be extended: AU-162 Board

Preparation:

• AUDIO IN: CH-1 400 Hz, +4 dBu


 AUDIO INPUT SELECT: PCM1 CH-1/CAM→CH-1

• AUDIO SELECT:

PCM1 AUTO/MAN→AUTO

• EE mode

Test point: TP1(GND: E1)/AU-162 Board Adjusting point: **②**RV1/AU-162 Board Specification: −18.0±0.2 dBu



7-3-10, PCM1 REC LEVEL ADJUSTMENT

Equipment: Audio level meter To be extended: AU-162 Board

Preparation:

AUDIO IN: CH-1 400 Hz, +4 dBu

 AUDIO INPUT SELECT: PCM1 CH1/CAM→CH-1

 AUDIO SELECT: PCM1 AUTO/MAN→AUTO

Adjust as follows while performing the self-recording/play
 To SOME to be

back with a E6-60ME tape.

Test point: TP1(GND: E1)/AU-162 Board Adjusting point: **⊘**RV5/AU-162 Board Specification: −14.0±0.5 dBu

7-3-11. PCM2 REC LEVEL ADJUSTMENT

Equipment: Audio level meter To be extended: AU-162 Board

Preparation:

• AUDIO IN: CH-2 400 Hz, +4 dBu

• AUDIO SELECT:

PCM2 AUTO/MAN→AUTO


Adjust as follows while performing the self-recording/play

back with a E6-60ME tape.

Test point: TP2(GND: E1)/AU-162 Board Adjusting point: ₱RV8/AU-162 Board

Specification: -14.0 ±0.5 dBu

AU-162 BOARD



7-3-12. LINE AU-1 MONITOR OUT LEVEL ADJUSTMENT

Equipment: Audio level meter To be extended: FP-40 Board

Preparation:

· AUDIO IN: CH-1 400 Hz, +4 dBu

• AUDIO INPUT SELECT: PCM1 CH-1/CAM→CH-1

· AUDIO SELECT:

PCM1 AUTO/MAN→AUTO

• MONITOR SELECT:

AFM/PCM→PCM

PCM1/ST • MIX/PCM2→ST • MIX

• EE mode

Test point: AUDIO OUT-L connector(terminated with $47k\Omega$)

Adjusting point: RV308/FP-40 Board

Specification: -10.0±0.2 dBu

7-3-13. LINE AU-2 MONITOR OUT LEVEL ADJUSTMENT

Equipment: Audio level meter To be extended: FP-40 Board

Preparation:

• AUDIO IN: CH-2 400 Hz, +4 dBu

AUDIO SELECT:

PCM2 AUTO/MAN→AUTO

• MONITOR SELECT:

AFM/PCM→PCM


PCM1/ST • MIX/PCM2→ST • MIX

• EE mode

Test point: AUDIO OUT-R connector(terminated with 47kΩ)

Adjusting point: **②** RV309/FP-40 Board Specification: −10.0±0.2 dBu

FP-40 BOARD



7-3-14. PCM1 METER ADJUSTMENT

Equipment: PCM1 level meter To be extended: FP-40 Board

Preparation:

· AUDIO IN: CH-1 400 Hz, +4 dBu


 AUDIO INPUT SELECT: PCM1 CH-1/CAM→CH-1

• AUDIO SELECT: PCM1 AUTO/MAN→AUTO

• EE mode

Adjusting point: • RV304/FP-40 Board Specification: The pointer should stay at 0.

PCM1 level meter



The pointer should stay at 0.

7-3-15. PCM2 METER ADJUSTMENT

Equipment: PCM2/AFM/BATT level meter

To be extended: FP-40 Board

Preparation:

· AUDIO IN: CH-2 400 Hz, +4 dBu

· AUDIO SELECT:


PCM2 AUTO/MAN→AUTO

• METER SELECT:
PCM2/AFM/BATT→PCM2

• EE mode

Adjusting point: • RV306/FP-40 Board Specification: The pointer should stay at 0.

PCM2/AFM/BATT level meter



7-3-16. AFM METER ADJUSTMENT

Equipment: PCM2/AFM/BATT level meter

To be extended: FP-40 Board

Preparation:

• AUDIO IN: CH-1 400 Hz, +4 dBu

AUDIO INPUT SELECT:
 PCM1 CH-1/CAM→CAM

AUDIO SELECT:
 AFM AUTO/MAN→AUTO

 METER SELECT: PCM2/AFM/BATT→AFM

• EE mode


Adjusting point: • RV305/FP-40 Board Specification: The pointer should stay at 0.

PCM2/AFM/BATT level meter



The pointer should stay at 0.

FP-40 BOARD



7-3-17. BATTERY METER ADJUSTMENT

Equipment: PCM2/AFM/BATT level meter


To be extended: FP-40 Board

Preparation:

1. POWER switch: OFF

2. METER SELECT switch (side panel)→"BATT"

Connect the DC IN connector/rear panel and the variable voltage power supply.



To supply power without using the XLR plug, set the MICRO switch (A) on the DC IN connector to ON. If the switch is OFF, power is not supplied to the EVW-300 unit.

4. POWER switch: ON Adjustment Procedure

- Turn the VARIABLE control on the variable voltage power supply slowly until the WARNING lamp/rear panel just starts to be light up.
- 2. Test point: PCM2/AFM/BATT level meter
 Adjusting point: PCM2/AFM/BATT level meter
 Adjusting point: RV307/FP-40 Board
 Specification: Adjust the RV307 so that the p

Specification: Adjust the RV307 so that the pointer stays on the left side of the green belt. (within a pointer width)

PCM2/AFM/BATT level meter



Adjust the RV307 so that the pointer stays on the left side of the green belt. (within a pointer width)

7-3-18. AUDIO AFM CARRIER FREQUENCY ADJUSTMENT

Equipment: Frequency counter To be extended: FP-40 Board

Preparation:

 AUDIO IN: No signal
 AUDIO INPUT SELECT: PCM1 CH-1/CAM→CAM

AUDIO SELECT:

AFM AUTO/MAN→AUTO

• EE mode

Test point: TP203 (GND: E1)/FP-40 Board Adjusting point: **②**RV201/FP-40 Board

Specification: 1.5±0.002 MHz

7-3-19. AFM DEVIATION ADJUSTMENT

Equipment: Audio level meter To be extended: FP-40 Board


Preparation:

Play back the Audio 400 Hz portion of the alignment tape

WR5-5NSP.

Test point: TP201 (GND: E1)/FP-40 Board Adjusting point: **②**RV202/FP-40 Board

Specification: -10.0±0.2 dBu



7-3-20. PCM REC CURRENT ADJUSTMENT

Equipment: Oscilloscope
To be extended: AU-162 Board


Preparation:


· Insert a E6-60ME tape.

• REC mode


Test point: TP101/SBX-1508 Board Trigger: TP110/AU-162 Board

Adjusting point: **②**RV103/AU-162 Board Specification: A=175±10 mVp-p





AU-162 BOARD



7-4. VIDEO SYSTEM ADJUSTMENT

Preparation:


• S1 (75%/100%)/IE-33 board→100%


Note: After the adjustment, return S1/IE-33 board to

 Open AU-162 board and remove four screws securing CR-43 board.

Turn the component side of CR-43 board toward you and fix with two screws as illustrated.

Be sure to put an insulating sheet between the CR-43 board and the unit.





7-4-1. PB RF FREQUENCY ADJUSTMENT

Equipment: Oscilloscope

Preparation:

 Connect the connector CN1 on the tracking adjustment fixture and the connector CN24 on the MB-384 Board.

2. Play back the alignment tape WR5-7NE.


Test point: TP4(GND: TPE1)/Tracking adjustment fixture

Trigger: TP3/Tracking adjustment fixture


Adjustment Procedure

1. TRIG mode/Oscilloscope → - side


 Adjusting point: ●RV102/SBX-1508 Board Specification: A(8.5MHz)=B(4.5MHz)×67%



- 3. TRIG mode/Oscilloscope→+side
- Adjusting point: ○RV101/SBX-1508 Board Specification: C(8.5MHz)=D(4.5MHz)×67%



Note: After the adjustment, remove the connector CN1 on the tracking adjustment fixture.



7-4-2. REC Y LEVEL ADJUSTMENT


Equipment: Oscilloscope
To be extended: VO-43 Board


Preparation:

OUTPUT switch/Camera side panel → BARS

• EE mode

Test point: TP1(GND: E1)/VO-43 Board Adjusting point: ♠RV251/VO-43 Board Specification: A=0.5±0.05 Vp-p





7-4-3. Y/C SEP ADJUSTMENT

Equipment: Oscilloscope
To be extended: VO-43 Board

Preparation:

1. OUTPUT switch/Camera side panel→BARS

Switch setting of the side panel
 SELF DIAG switch→ON
 ②REGEN/PRESET switch→PRESET

③R-RUN/SET/F-RUN switch→SET


♠ADVANCE/SHIFT button→Set the Menu Number to 104.

⑤R-RUN/SET/F-RUN switch→R-RUN ⑥ADVANCE/SHIFT button→Set to 2.

Put the RESET button.




3. S801/V0-43 Board→A side




4. S1(VTR-TEST)/ES-4 Board→Under side

5. EE mode

Test point: TP254(GND: E1)/VO-43 Board Adjusting point: **②**RV252, **③**RV701/VO-43 Board Specification: Level "A"=Minimum (≤20 mV)



Note: After the adjustment, set switches as follows. S801/V0-43 Board→® side S1(VTR-TEST)/ES-4 Board→Upper side SELF DIAG switch(side panel)→OFF




7-4-4. IR ADJUSTMENT


Equipment: Oscilloscope
To be extended: VO-43 Board

Preparation:

- 1. POWER switch→OFF
- 2. R848 (A SIDE; zone A-3)/VO-43 Board→Delete
- 4. POWER switch→ON
- 5. OUTPUT switch/Camera side panel→BARS
- 6. Switch setting of the side panel
 ①SELF DIAG switch→ON
 ②REGEN/PRESET switch→PRESET
 ③R-RUN/SET/F-RUN switch→SET
 - ♠ADVANCE/SHIFT button→Set the Menu Number to 104.
 - ⑤R-RUN/SET/F-RUN switch→R-RUN
 - ⑥ADVANCE/SHIFT button→Set to 2.
 - Put the RESET button.




7. S801/VO-43 Board→@side



8. S1(VTR-TEST)/ES-4 Board→Under side

9. EE mode

Test point: TP252(GND: E1)/VO-43 Board Adjusting point: **Q**RV254/VO-43 Board Specification: Level "A" \rightarrow Minimum



Note: After the adjustment, set switches as follows.

POWER switch→OFF

S801/V0-43 Board→®side

S1(VTR-TEST)/ES-4 Board→Upper side

R848/V0-43 Board→Return to normal position.

CL692(soldering side)/V0-43 Board→Return to normal position.

SELF DIAG switch(side panel)→OFF


7-4-5. EMPHASIS LEVEL ADJUSTMENT


Equipment: Oscilloscope
To be extended: V0-43 Board

Preparation:

- OUTPUT switch/Camera side panel→BARS
- EE mode

Test point: TP253(GND: E1)/VO-43 Board Adjusting point: **②**RV301/VO-43 Board Specification: A=0.45±0.05 Vp-p






7-4-6. CHROMA EMPHASIS ADJUSTMENT

Equipment: Oscilloscope
To be extended: CR-43 Board

Preparation:

• OUTPUT switch/Camera side panel→BARS Test point: TP601 (GND: E101)/CR-43 board Adjusting point: **②**FL602/CR-43 Board



7-4-7. HIS MODE PB Y LEVEL ADJUSTMENT


Equipment: Oscilloscope
To be extended: V0-43 Board

Preparation:


Play back the color-bar signal portion of the alignment tape


WR5-8NSE.

Test point: TP251(GND: E1)/VO-43 Board Adjusting point: ♠RV201/VO-43 Board Specification: A=0.5±0.05 Vp-p



CR-43 BOARD





7-4-8. STD MODE PB Y LEVEL ADJUSTMENT


Equipment: Oscilloscope
To be extended: VO-43 Board

Preparation:

• Play back the color-bar signal portion of the alignment tape

WR5-8NSE.

Test point: TP251(GND: E1)/VO-43 Board Adjusting point: ♠RV202/VO-43 Board Specification: A=0.5±0.05 Vp-p



7-4-10. EE LINE OUT LEVEL ADJUSTMENT

Equipment: Oscilloscope
To be extended: VO-43 Board

Preparation:


· OUTPUT switch/Camera side panel→BARS

• EE mode

Test point: VIDEO OUT

Adjusting point: • RV1/VO-43 Board

Specification: $A=1.0\pm0.05$ Vp-p (terminated with 75 Ω)



7-4-9, PB Y LEVEL ADJUSTMENT


Equipment: Oscilloscope
To be extended: VO-43 Board


Preparation:

Play back the color-bar signal portion of the alignment tape

WR5-8NSE.

Test point: TP253(GND: E1)/V0-43 Board Adjusting point: **②**RV302/V0-43 Board Specification: A=0.52±0.05 Vp-p





7-4-11. PB LINE OUT LEVEL ADJUSTMENT

Equipment: Oscilloscope
To be extended: VO-43 Board


Preparation:

 Play back the color-bar signal portion of the alignment tape WR5-8NSE.


Test point: VIDEO OUT

Adjusting point: • RV2/VO-43 Board

Specification: $A=1.05\pm0.05 \text{ Vp-p}$ (terminated with 75 Ω)



VO-43 BOARD




7-4-12. LOW BAND MODE Y FM CARRIER ADJUSTMENT

Equipment: Oscilloscope, Frequency counter

To be extended: VO-43 Board


Preparation:

· Connect the oscilloscope and frequency counter as follows.



- · SELF DIAG switch/side panel→ON
- · Insert a P6-60MP tape.
- EE mode

Test point: TP10(GND: E1)/V0-43 Board Adjusting point: **⊘**RV259/V0-43 Board Specification: 4.40±0.02 MHz



Note: After the adjustment, set the switches as follows.

①SELF DIAG switch/side panel→OFF

②POWER switch/side panel→OFF

7-4-13. LOW BAND MODE Y FM DEVIATION ADJUSTMENT


Equipment: Oscilloscope
To be extended: V0-43 Board

Preparation:


Adjust as follows while performing the self-recording/play

back with a P6-60MP tape.

Test point: TP253(GND: E1)/VO-43 Board Adjusting point: **②**RV258/VO-43 Board Specification: A=0.5±0.025 V



VO-43 BOARD




7-4-14. HIS MODE Y FM CARRIER ADJUSTMENT

Equipment: Oscilloscope, Frequency counter

To be extended: VO-43 Board

Preparation:

• Connect the oscilloscope and frequency counter as follows.



- SELF DIAG switch/side panel→ON
- Insert a E6-60ME tape.
- EE mode

Test point: TP10(GND: E1)/VO-43 Board Adjusting point: • RV256/VO-43 Board

Specification: 6.00 ± 0.02 MHz

Note: After the adjustment, set the switches as follows.

①SELF DIAG switch/side panel→OFF ②POWER switch/side panel→OFF


7-4-15. HIS MODE Y FM DEVIATION ADJUSTMENT

Equipment: Oscilloscope
To be extended: VO-43 Board

Preparation:

• Perform the self-recording/play back with a E6-60ME tape.

Test point: TP253(GND: E1)/VO-43 Board Adjusting point: **②** RV255/VO-43 Board Specification: A=0.5±0.025 V



7-4-16. REC VIDEO REC CURRENT LEVEL ADJUSTMENT

Equipment: Oscilloscope To be extended: VO-43 Board

Preparation:

- · Insert a E6-60ME tape.
- · REC mode
- · Connect between these points with shorting clips.


TP202/FP-40-TP109/AU-162 TP110/AU-162→TP109/AU-162


Test point: TP101/SBX-1508 Board Adjusting point: ORV403/VO-43 Board

Specification: A=160±10mA




Note: After the adjustment, remove a shorting clip.






VO-43 BOARD



AU-162 BOARD



7-4-17. REC CHROMA REC CURRENT ADJUSTMENT

Equipment: Oscilloscope
To be extended: VO-43 Board

Preparation:


POWER switch/side panel→0FF
 C425, C426, C429/VO-43→Delete

3. POWER switch/side panel→ON


4. Insert a E6-60ME tape.


5. REC mode


Test point: TP101/SBX-1508 Board Adjusting point: ♠RV402/VO-43 Board Specification: Chroma level A=43±2 mV




Note: After the adjustment, return C425, C426 and C429/ VO-43 to normal position.







Note: Do not use the prove of 10: 1 in this adjustment because the signal level of TP101 is low. Connect directly oscilloscope through 100 ohms resistor as shown in the figure.




Equipment: Oscilloscope
To be extended: VO-43 Board


Preparation:


- 1. POWER switch/side panel→OFF
- 2. C426, C427, C429/VO-43→Delete
- 3. POWER switch/side panel→ON
- 4. Insert a E6-60ME tape.
- 5. REC mode


Test point: TP101/SBX-1508 Board Adjusting point: ♠RV401/VO-43 Board Specification: AFM level A=7±1 mV




Note: After the adjustment, return C426, C427 and C429/ V0-43 to normal position.







CR-43 BOARD



7-4-19. CHROMA CANCEL BALANCE ADJUSTMENT


Equipment: Oscilloscope
To be extended: CR-43 Board

Preparation:

· OUTPUT switch/Camera side panel→BARS

· REC mode

Test point: TP8(GND: E101)/CR-43 Board Adjusting point: ♠RV901/CR-43 Board Specification: Level "A"→Minimum



7-4-20. C CORRELATION PHASE ADJUSTMENT 1

Equipment: Oscilloscope
To be extended: CR-43 Board

Preparation:


OUTPUT switch/Camera side panel→BARS

 Connect between these points on the CR-43 Board with shorting clips. TP106/CR-43→E101/CR-43

• EE mode

Test point: TP101(GND: E101)/CR-43 Board Adjusting point: **O**RV801, **O**CV102/CR-43 Board

Specification: Chroma level→Minimum



Note: After the adjustment, remove a shorting clip.

7-4-21, C CORRELATION PHASE ADJUSTMENT 2

Equipment: Oscilloscope
To be extended: CR-43 Board

Preparation:

· OUTPUT switch/Camera side panel→BARS


· Connect between these points on the CR-43 Board with

shorting clips. TP106/CR-43→E101/CR-43

• EE mode


Test point: TP102(GND: E101)/CR-43 Board Adjusting point: • RV800, • CV101/CR-43 Board

Specification: Chroma level→Minimum



Note: After the adjustment, remove a shorting clip.

CR-43 BOARD



7-4-22. C CORRELATION PHASE ADJUSTMENT 3

Equipment: Oscilloscope
To be extended: CR-43 Board

Preparation:


· OUTPUT switch/Camera side panel→BARS

 Connect between these points on the CR-43 Board with shorting clips. TP106/CR-43→E101/CR-43

• EE mode

Test point: TP105(GND: E101)/CR-43 Board Adjusting point: • RV802, • CV103/CR-43 Board

Specification: Chroma level→Minimum



Note: After the adjustment, remove a shorting clip.

Play back the color-bar signal portion of the alignment tape WR5-8NSE.

Test point: VIDEO OUT

To be extended: VO-43 Board

Equipment: Vectorscope


Preparation:

Adjustment Procedure

• Adjust ✔ RV601/CR-43 Board so that the red beam spot is

located in the "H" mark on the vectorscope.

7-4-24. PB CHROMA LEVEL ADJUSTMENT



7-4-23. EE VIDEO OUT CHROMA LEVEL ADJUSTMENT

Equipment: Vectorscope
To be extended: CR-43 Board

Preparation:


OUTPUT switch/Camera side panel→BARS

• EE mode

Test point: VIDEO OUT/EVW-300 rear panel

Adjustment Procedure

• Adjust • RV902/CR-43 Board so that the red beam spot is located in the "\mathbb{H}" mark on the vectorscope.



CR-43 BOARD

